



2N[®] OfficeRoute

2N[®] VoiceBlue Enterprise



User Manual

Version 1.7.0
Firmware 2.3.1

www.2n.cz

The 2N TELEKOMUNIKACE joint-stock company is a Czech manufacturer and supplier of telecommunications equipment.



The product family developed by 2N TELEKOMUNIKACE a.s. includes GSM gateways, private branch exchanges (PBX), and door and lift communicators.

2N TELEKOMUNIKACE a.s. has been ranked among the Czech top companies for years and represented a symbol of stability and prosperity on the telecommunications market for almost two decades. At present, we export our products into over 120 countries worldwide and have exclusive distributors on all continents.



2N® is a registered trademark of 2N TELEKOMUNIKACE a.s.. Any product and/or other names mentioned herein are registered trademarks and/or trademarks or brands protected by law.



Declaration of Conformity

2N TELEKOMUNIKACE a.s. hereby declares that the 2N® OfficeRoute/2N® VoiceBlue Enterprise product complies with all basic requirements and other relevant provisions of the 1999/5/EC directive. For the full wording of the Declaration of Conformity see the CD-ROM enclosed and at www.2n.cz.



2N TELEKOMUNIKACE company is a holder of the ISO 9001:2000 certificate. All development, production and distribution processes of the company are managed by this standard and guarantee a high quality and advanced technical level of and a professional approach to all of our products.

Contents

1. Product Overview.....	7
1.1 Product Description	8
Product Presentation	8
How to Save Telephone Costs	8
Other Advantages and Applications	8
RF Radiation Safety Precautions	9
1.2 Changes	10
1.3 Terms and Symbols Used	11
Manual Symbols	11
2. Description and Installation	12
2.1 Product Description	13
2.2 Before Installation	14
Packing List	14
Brief Installation Guide	14
2.3 Mounting	16
Proper Mounting	16
Gateway Power Supply	17
2.4 PC Connection and LAN Connection	18
PC Connection	18
LAN Connection	19
2.5 Antenna Connection	20
2.6 SIM Card Insertion.....	21
2.7 Status Indicators	22
Power Indicator.....	22
GSM Indicators.....	22
2.8 Console Access.....	24
Serial Console Access	24
Submenus	24
Commands and Values	25
About Menus.....	26
Telnet Console Access.....	27
3. Configuration.....	29
3.1 Web Browser Configuration.....	30
Web Browser Access	30
Configuration Wizard	30

3.2	Web Access	37
3.3	Survey of Group Tags and Menus	39
3.4	Network Settings	40
3.5	User Management	48
3.6	Telephony Services.....	52
	VoIP Network Arrangement.....	52
	Routing	55
	Devices.....	56
	SIP Lines	57
	H.323 Lines	59
	SIM Cards.....	61
	DISA Line	64
	Fax Lines	66
	Fxs Line	66
	GSM	67
	Services.....	69
	Mobility Extension	70
	Fax.....	71
	LCR	72
	GSM Routing	80
	SIP Proxy.....	83
3.7	Administration	86
	Main Configuration	86
	Set Time zone	86
	Synchronise Time.....	87
	Update Firmware	87
	Upload Licence.....	88
	Configuration Backup	88
	Reboot	88
3.8	States and Logs.....	90
	States	90
	Call Accounting.....	91
	Logs.....	92
	Download Logs.....	93
	Connection Speedometer.....	93
3.9	Messaging	95
	SMS sending	95
	SMS Delivery.....	96
	VIP Numbers	98
	SMTP IP Access.....	99

4.	Function and Use	101
4.1	Factory Reset.....	102
5.	Technical Parameters	103
5.1	Technical Parameters	104
	VoIP	104
	Mobile networks.....	104
	Antenna	104
	Power Supply	104
	Interface.....	105
	Operational Conditions	105
	Others	105
6.	Supplementary Information	107
6.1	Regulations	108
6.2	Troubleshooting	109
6.3	List of Figures	110
6.4	General Instructions and Cautions	114
	Electric Waste and Used Battery Pack Handling	115

1

Product Overview

In this section, we introduce the 2N® OfficeRoute/2N® VoiceBlue Enterprise, outline its application options and highlight the advantages following from its use.

Here is what you can find in this section:

- Product Description
- Changes
- Terms and Symbols Used

1.1 Product Description

Product Presentation

- The 2N® OfficeRoute/2N® VoiceBlue Enterprise gateways provide a direct interconnection of VoIP, GSM and UMTS (UMTS only in 2N® OfficeRoute) networks with the support of SIP and H.323 signalling protocols.
- The voice mode, i.e. outgoing or incoming calls, is the basic function of the system. The gateway is equipped with all functions necessary for such use and provides a very high comfort in this mode.
- The data mode, i.e. HSPA/EDGE/GPRS (for 2N® OfficeRoute) or GPRS (for 2N® VoiceBlue Enterprise) data router, gives a possibility to the device as a router, firewall and DNS proxy. It also has a DHCP server functionality. There is also a very unique feature – VRRP+ (Virtual Router Redundancy Protocol) so it can serve as a back-up route for your Internet connectivity.
- In addition to voice transmission, 2N® OfficeRoute/2N® VoiceBlue Enterprise can send and receive short text messages (SMS). It gives you an option to integrate the SMS functionality into your email client (i.e. MS Outlook).
- 2N® OfficeRoute/2N® VoiceBlue Enterprise contains a built-in SIP proxy server and can thus serve as an IP PBX for SIP telephones.
- No extra equipment (an external GSM telephone, etc.) is needed for normal operation. All programmable parameters are default-preset in such a manner that you can commence your telephone traffic the moment you connect the Ethernet and supply the cables, antenna and SIM card and set the IP parameters.

How to Save Telephone Costs

- You are advised to use the **most advantageous tariff of your GSM provider** for your UMTS/GSM calls.
- You can bar selected numbers or groups of numbers in your gateway. **You shall pay nothing for the calls you have barred.**
- 2N® OfficeRoute/2N® VoiceBlue Enterprise keeps detailed records on all calls. This helps you **find out easily why your bill is higher than it should be.**
- The Least Cost Router is flexible enough to help you set rules for **GSM/UMTS/SIP/H.323 calling at the lowest possible operation costs.**

Other Advantages and Applications

- 2N® OfficeRoute/2N® VoiceBlue Enterprise integrates the best of all communication technologies.
- With the aid of a built-in SIP proxy server you can create a **complete VoIP network without additional third party products' costs.**

- The **intelligent routing of incoming calls** accelerates the connection of incoming calls and makes calling more comfortable.
- An easily recordable DISA voice message function is available.
- You can use the fax whether or not you have a CO line.
- You will not lose any call with the internal VoiceMail and Mobility Extension features.
- Unlike cellular phones, this system does not expose you to the RF electromagnetic field while making calls.

RF Radiation Safety Precautions



Safety, warnings

- It is prohibited to use any transmitters, including UMTS/GSM devices, in areas where explosives are used, such as quarries.
- A GSM/UMTS device may affect sensitive life-saving devices in medical centres.
- In general, any prohibition regarding mobile phones based on RF energy radiation applies to GSM/UMTS devices.
- Where necessary, a 2N[®] OfficeRoute system may be installed at a safe distance (in the neighbouring building, e.g.) and an Ethernet cable may be carried from the system gateway to the original building.
- Although 2N[®] OfficeRoute is not intended for aeroplanes, all relevant prohibitions and regulations regarding mobile phones apply to them here

1.2 Changes

The manufacturer reserves the right to modify the product in order to improve its qualities.



Caution

- The manufacturer constantly improves the software contained in the product (the so-called firmware). The technology used therein helps you download the latest firmware version to 2N® OfficeRoute/2N® VoiceBlue Enterprise anytime using a standard PC. For the latest firmware version see **www.2n.cz**. We recommend you to apply the latest version to avoid problems that have already been eliminated.
- Also find the latest version of the User Manual at **www.2n.cz**.
- Check your delivery for completeness according to the packing list and study this manual carefully before installing this product. The manufacturer shall not be responsible for damage caused by any use of this product that is in contradiction with the User Manual. The warranty terms and conditions do not apply to damage incurred as a result of gross handling and/or undue storing of the product or violation of the technical parameters included herein.
- This manual is very much detailed and includes subsections that are irrelevant for the basic installation purposes as well as subsections referring to other 2N® OfficeRoute/2N® VoiceBlue Enterprise models. Therefore, pay attention to hints informing you which subsections are necessary for you and which are not.
- For more information on the 2N® OfficeRoute/2N® VoiceBlue Enterprise settings and features see **faq.2n.cz**

1.3 Terms and Symbols Used

Manual Symbols



Safety

- **Always** abide by this information to prevent persons from injury.



Warning

- **Always** abide by this information to prevent damage to the device.



Caution

- **Important information** for system functionality.



Tip

- **Useful information** for quick and efficient functionality.



Note

- Additional information.

2

Description and Installation

This section shows how to install the 2N® OfficeRoute/2N® VoiceBlue Enterprise gateway including all accessories.

Here is what you can find in this section:

- Product Description
- Before Installation
- Mounting
- PC Connection and LAN Connection
- Antenna Connection
- SIM Card Insertion
- Status Indicators
- Console Access

2.1 Product Description

Before you start installing your 2N® OfficeRoute/2N® VoiceBlue Enterprise, please get familiar with its physical structure, arrangement of connectors and status indicators.




Fig. 1 – Bottom View




Fig. 2 – Top View

2.2 Before Installation

Packing List

Please check whether the contents of the package of your new 2N® OfficeRoute/2N® VoiceBlue Enterprise complies with the following list.

- 1x 2N® OfficeRoute – check order number, see the type label on the gateway back side
- 1x 12V/2.5 A mains adapter
- 1x USB cable
- 1x ETHERNET cable
- 1x Antenna
- 1x Wall mounting holder
- 2x Dowel
- 2x Screw
- Quick user guide
- Compliance certificate
- 2N product CD
- Warranty certificate

Brief Installation Guide

- **Proper mounting** – 2N® OfficeRoute/2N® VoiceBlue Enterprise is designed for suspension on a vertical surface. Fit the holder included in the delivery on a wall and hang the gateway on it. For details on the prescribed working position and other recommendations refer to Section 2.4.
- **Cable connection** – connect the gateway using a patch-cable to the LAN (Local Area Network).
- **Antenna connection** – connect an internal antenna or an external antenna cable to the SMA antenna connector. Install the external antenna on a place with a good UMTS/GSM signal.
- **Gateway power supply** – the delivery includes a mains adapter. Plug in the adapter connector into the gateway and the power adapter into a mains socket (≈230V/50Hz). The gateway turns on immediately.
- **SIM card insertion** – insert the SIM cards in the holders on the gateway top.
- **PC connection and initial configuration** – a web browser is used for gateway configuration in normal operation. If you have not defined the IP address for the gateway, use the USB cable included in the delivery for initial configuration of the basic parameters or reach 2N® OfficeRoute/2N® VoiceBlue Enterprise on its default IP address 192.168.1.1.

- **Setting and monitoring** – having set the basic network parameters (IP address, etc.), you can configure 2N® OfficeRoute/2N® VoiceBlue Enterprise using a standard web browser (http or https). Configuration options and essential procedures shall be discussed in detail in the respective sections.

2.3 Mounting

Proper Mounting

- The device is designed for mounting on a vertical surface. For this purpose, a wall-mounting holder is available. Just fit the holder to the wall using dowels and screws and hang the device.




Fig. 2.1– Gateway Holder - Wall Mounting




Fig. 2.2– Gateway Holder – Hanging

- It is possible to operate this device in another working position (e.g. on a desk) but it may deteriorate the GSM signal if the antenna is situated horizontally.
- Do not exceed the allowed working temperature and relative humidity ranges.
- Exceeding the recommended operating temperature values need not affect the gateway function immediately but may result in a more rapid ageing and lower reliability.

- The device is intended for indoor use only. It may not be exposed to rain, flowing water, condensed moisture, fog, or mist.
- The device may not be exposed to aggressive gas, acid vapours, solvents, etc. or aggressive liquids, during cover cleaning, for example.
- The device is not designed for high-vibration environments, e.g. means of transport, machine rooms, etc.
- Free space has to be left under and over the device for cables and agitated air to remove operational heat.
- Install the device on a place with a good UMTS/GSM signal.
- A misplacement of the GSM/UMTS device or its antenna near television, broadcasting or similar RF-sensitive devices may exercise an adverse effect upon their function.
- Being a source of RF energy emission, the device antenna should not be located close to human bodies. The hazard is higher than with mobile phones because the device is usually used by many people and thus employed more often.

Gateway Power Supply

Be sure to use only the mains adapter that is included in your 2N® OfficeRoute/2N® VoiceBlue Enterprise delivery.



Caution

- Before plugging in the device, make sure that the mains voltage value meets the data given on the mains adapter label.
- Furthermore, make sure that the antenna has been connected. If you connect the device to the power supply without an antenna, the UMTS/GSM module transmitter might get damaged.

Now plug the mains adapter into a mains socket and connect the adapter connector to the device. The status indicators indicate the proper operation.




Fig. 2.3– Supply Adapter Connection

2.4 PC Connection and LAN Connection

PC Connection

You need a direct interconnection of your 2N® OfficeRoute/2N® VoiceBlue Enterprise gateway and PC especially when you do not know the gateway IP address and thus cannot configure it using a web browser. In such a case, connect the gateway directly to your PC USB port with the cable enclosed and select the basic network parameters using your console interface. After the gateway is connected using the USB cable, the PC detects new hardware. You have to choose the driver for 2N® OfficeRoute, available on the CD in the package.

You can control the console interface with any terminal-emulating program according to the VT-100 specification at least such as HyperTerminal or PuTTY.



Note

- The HyperTerminal is not installed by default in Microsoft Windows Vista. For serial connection to the gateway use an alternative program such as PuTTY.

By default, the gateway serial port communication parameters are set at **921,600 bits per second, 8 data bits, no parity, 1 stop bit, no flow control**. Set the communication program on the PC side identically. If you are using PuTTY for serial communication, you can use settings as shown in Fig. 2.4. It is necessary to choose the **Serial** connection type and the COM number on which the gateway is connected for the serial line type. The rate is 921600. Click on the *Open* button.




Fig. 2.4– PuTTY – Serial Console Access Configuration

LAN Connection

2N® OfficeRoute/2N® VoiceBlue Enterprise is connected to the 10/100BASE-T (Twisted Pair Ethernet) LAN using a standard straight (non-crossed) cable terminated with RJ-45 connectors like other types of equipment (PC, etc.).




Fig. 2.5– LAN Connection

2.5 Antenna Connection

No matter whether equipped with one UMTS and one, two or three GSM modules, 2N® OfficeRoute/2N® VoiceBlue Enterprise has just one SMA antenna connector, to which an external antenna cable is connected. This external antenna should be installed vertically on a place with a good UMTS/GSM signal.




Fig. 2.6– Antenna Connector Connection



Caution

- Tighten the antenna connector **gently** with your hand, never use a wrench!

2.6 SIM Card Insertion

Insert your SIM card in the device and fix it with a small lock (move the lock over the inserted SIM card).



Caution

- You cannot replace SIM cards with your device on.




Fig. 2.7– SIM Card Inserting Procedure

2.7 Status Indicators

There is a panel with five LEDs on the gateway upper cover. The **Power** indicator signals that the gateway as a whole is in operation. The other LEDs, marked **CH 1** through **CH 4**, indicate the status of each module.

Power Indicator

Basic diagnostic tests are performed automatically whenever the gateway is connected to the supply voltage. Each test step is signalled by a specific colour combination of the LEDs. The testing process is usually shorter than 0.5 sec and so it looks like a quick sequence of LED flashes at first sight. If, however, a test step fails, the indicator combination related to the failed test remains on. This provides a convenient troubleshooting tool to the technical support personnel.

After all hardware tests have been completed successfully, the operating system kernel is loaded. During the process, all module indicators are off and the blue continuous **Power** light flashes in approximately 1-second intervals.

When the operating system kernel has been loaded, the blue **Power** indicator keeps shining continuously.

In exceptional cases, when a fatal software error occurs and the gateway stops working, the **Power** indicator starts flashing quickly. All you can do is disconnect the gateway from the power supply for a few seconds and then restart it.

<i>Power Indicator (blue)</i>	
No light	The system is not working.
Flashing	The system kernel is being loaded.
Continuous light	The system is working.
Quick flashing	Fatal error

GSM Indicators

The **CH 1** - **CH 4** indicators indicate the signal status of the respective GSM module. After connection to the power supply, the VoIP gateway application starts running within two minutes. During that time, the installed GSM modules and SIM cards are detected. If not detected, the respective indicator remains off.

If detected, the module and SIM card initialisation process is commenced. If the process is unsuccessful, the LED goes red. If the indicator turns orange, it means that the module has not logged in to any GSM network.

If the LED is off, you can make calls and send SMS via the respective module.

The respective module LED flashes green quickly during call set-up or data connection in the case of UMTS module. When the connection has been established successfully, the indicator remains green during the whole call.

GSM Indicators	
No light	The module is ready.
Red light	SIM card initialisation in progress or no SIM card is in the drawer.
Yellow/Orange light	The SIM is not logged-in to any GSM network.
Quick green blinking	A call is being set up (dialled). Data connection active.
Green light	A call is being made.

2.8 Console Access

You need a direct interconnection of your 2N® OfficeRoute/2N® VoiceBlue Enterprise gateway and PC especially when you do not know the gateway IP address and thus cannot configure it using a web browser. Also you can configure the DHCP server in the gateway or the VRRP function.

The console system is arranged as a set of nested menus. Entering a menu item number you either get into a submenu, or have the required operation executed, or set the selected parameter.

Serial Console Access

When the gateway is powered on, the main menu should get displayed after terminal connection.

When you are connected by a serial console, push *Enter* to display the main menu.

```
UMTS OfficeRoute V2.3.0beta2      Main Menu      voiceblue
  Option      Value      Description

1 - Configuration      [ menu ]      - General configuration
2 - Set Admin password      - Set administration password
3 - Help              - Display help for serial console settings

Enter an option number, <ESC> previos menu
>
```

Fig. 2.8 – Serial Console Access – Main Menu

Every menu consists of the following parts:

- **Header**
contains (from the left) - product name, firmware version, menu name and network name assigned to the equipment.
- **Options**
displays the numbers and names of available options.
- **Value**
if [menu] is displayed, the item includes a submenu. Otherwise it shows the current value of the option.
- **Description**
explains briefly the meaning of every option in the menu.
- **Enter an option number...>**
there enter the option number.

To select an option from a menu, enter its first number and push *Enter* for confirmation.

Submenus

If you select a submenu, this submenu gets displayed. Now you can select items from the selected submenu or push *Esc* for return.

Commands and Values

If you are requested to enter some information after selecting an item, you should enter one of the following values:

- **Key word**

a list of one or more fixed strings. To select one, enter only so many initial characters as can distinguish it unambiguously from other key words.

Enter one of [ansi,color,teletype] : a

In the above mentioned case, select the key word by entering just an 'a', 'c', or 't' and push *Enter*.

- **String**

an arbitrary number of characters. The acceptable value interval may be included in the prompt.

Enter a hostname from 1 to 32 characters: OfficeRoute

- **Integer**

A decadic integral number. The acceptable value interval may be included in the prompt.

Enter a size between 1 and 100 : 99

A hexadecimal integral number – number to be entered in the hexadecimal format using characters 0÷9 and a÷f or A÷F.

Enter a hex number between 1h and ffh : 1a

- **MAC address**

up to 12 hexadecimal digits of the physical address. Zeros at the beginning can be omitted.

Enter the remote network address : 50C229C4E2

- **IP address**

an Internet address in the format of four digits of 0÷255 separated with dots.

Enter an IP address - 192.168.22.30

As soon as the requested information is entered, the respective operation is executed and new values are displayed in the redrawn menu.

Some configuration parameters may have just one of two constant values. By selecting such an item you immediately select a value opposite to that preceding the selection. Typical examples are *on* and *off* parameters. If the value is *on*, then it becomes *off* when the item is selected and vice versa.

Some commands execute operations that have a serious impact on the behaviour of the entire system (such as restart). Therefore, the system usually 'makes sure' before execution that it is really your intention.

Are you sure [y/n] :

If you give an answer other than 'y' or 'Y', the command will not be executed.

To cancel the command execution and quit the prompt, push the *Esc* key any time.

About Menus...

We shall discuss the serial console menus in detail in the sections devoted to the gateway parameter settings. Below is a brief survey of these menus only.

Main menu

appears after the USB cable is connected to the terminal (sometimes you must push *Enter*).

Configuration menu

contains six submenus - network configuration, serial console settings, command line configuration, calls and device states, reboot and settings of VRRP and DHCP.

Network configuration

used for setting the gateway IP address, network mask, initial router, DNS addresses, network name and domain.

```
UMTS OfficeRoute V2.3.0beta2Network Configuration Menu voiceblue
e
  Option              Value              Description
1 - Address           [ 192.168.200.3 ] - Internet address
2 - Network Mask      [ 255.255.255.0 ] - Internet subnet mask
3 - Gateway           [ 192.168.200.1 ] - Internet default gateway
4 - Routing           [ menu ] - IP routing table configuration
5 - Dns1              [ 192.168.200.1 ] - DNS server 1
6 - Dns2              [ 0.0.0.0 ] - DNS server 2
7 - Host name         [ "voiceblue" ] - Host name
8 - Domain            [ "" ] - Domain name
9 - Dhcp              [ on ] - Use DHCP on startup
01 - HW Addr          [ 00:50:C2:81:F8:71 ] - Ethernet HW Address

Enter an option number, <ESC> previous menu
>
```

Fig. 2.9 – Serial Console – Network Configuration

- **Address**
the IP address of the gateway. If the dynamic address obtaining function using the DHCP is enabled, the value cannot be changed manually.
- **Network mask**
the network mask. If the dynamic address obtaining function using the DHCP is enabled, the value cannot be changed manually.
- **Gateway**
the initial router IP address. It is used for routing the data traffic beyond the network limits. If the dynamic address obtaining function using the DHCP is enabled, the value cannot be changed manually.
- **DNS1**
IP address of the first DNS.
- **DNS2**
IP address of the second DNS.

- **Host name**
the network name of the GSM gateway.
- **Domain**
the domain name.
- **Location**
any text describing the gateway location. This value is published through the SNMP (in special firmware versions).
- **Contact**
a text containing the gateway administration contact information. This value is published through the SNMP (in special firmware versions).
- **DHCP**
a mark of the dynamic address assignment function. If selected, the gateway gets its network settings from the DHCP server. If not, the values must be entered manually.
- **Class**
the equipment class name that is sent in the network setting sending request. This string can help the DHCP server distinguish different types of equipment and assign configuration parameters to them accordingly.

The *DHCP* or *Address/Network mask* parameters at least must be set correctly for the gateway communication to be established within the TCP/IP network. The address of one DNS at least should be set too.

- **Serial console configuration**
helps set the terminal type and change the initial serial link parameters – transmission rate, data and stop bits, parity and flow control type.
- **Command line**
allows you to set/change basic telephony settings – LCR, routes, SIP, devices, calls, DISA.
- **States**
the states of devices (signal strength, registration status, etc.) and calls.
- **Reboot**
this option restarts the device.
- **Settings**
the DHCP and VRRP server settings.

Telnet Console Access

This is a short description of new features added to the serial console configuration. For the standard serial console configuration capabilities refer to the section 2.11.

There is also a possibility of using Telnet for 2N[®] OfficeRoute configuration in addition to the standard serial console configuration.

Connect to your 2N[®] OfficeRoute via the Telnet type **telnet <your OfficeRoute IP address>** in the command line.

If successful, 2N[®] OfficeRoute will require authentication from you. To log in, use the valid login and password of one of the 2N[®] OfficeRoute users in the Administrators

group. No user other than a member of the Administrator group may log in. If the login and password are entered correctly, you will be logged in.

Now you will see a window similar to the standard serial console configuration window and you can work with it in the same way. To log out, get to the main menu and choose the *Logout* option (this option is not visible in the serial console window).

There are all menus available as for the USB access.

**Note**

- The Telnet function may not be enabled by default in Microsoft Windows Vista. For a Telnet console access enable the Telnet client.

3

Configuration

This section describes the web browser configuration.

Here is what you can find in the section:

- **Chyba! Nenalezen zdroj odkazů.**
- **Chyba! Nenalezen zdroj odkazů.**
- Survey of Group Tags and Menus
- Network Settings
- User Management
- Telephony Services
- Administration
- States and Logs
- Messaging

3.1 Web Browser Configuration

Web Browser Access

While the serial console interface enables you to change the basic gateway parameters only, the web browser gives you access to all parameter settings and services available in the 2N[®] OfficeRoute gateway. To establish connection with the gateway, enter the gateway IP address into the Internet address setting line in the browser, e.g.: Mozilla Firefox or Internet Explorer.

If you have connected all parts properly and set the correct gateway and PC IP addresses, the configuration wizard should get displayed.

Configuration Wizard

If you are connecting to the 2N[®] OfficeRoute gateway the first time or after a factory reset, the configuration wizard should appear. The configuration wizard will lead you through the 2N[®] OfficeRoute setting. After entering the required information you will be able to use a high speed data Internet connection, make outgoing and incoming calls to GSM and UMTS networks and benefit from the PBX features.






Fig. 3.1 – Configuration Wizard - Introduction

1. Administrator Password

Enter a new administrator password for login to the web interface. It is important to change the password to ensure your data security. The administrator username is Admin. Store your password (default = 2n) by clicking on the icon in the navigation bar.

1. Introduction

2. Administrator's password

3. Timezone

4. PIN codes for SIM cards

5. Data connection

6. Extension number allocation

7. Passwords for extensions

8. Outgoing calls through VoIP operator

9. Outgoing calls through GSM/UMTS

10. Incoming calls

11. Finish

2. Administrator's password

Enter a new administrator password for logging on to the web interface. It is important to change the password to ensure the security and protection of your data. The administrator username is Admin.



New password:

Confirm new password:

Fig. 3.2 – Configuration Wizard – Administrator Password

2. Time zone

Select the applicable time zone. A correct time zone setting is important for a proper working of the time-related features and call records. It also ensures a due switching of the daylight-saving time.

1. Introduction

2. Administrator's password

3. Timezone

4. PIN codes for SIM cards

5. Data connection

6. Extension number allocation

7. Passwords for extensions

8. Outgoing calls through VoIP operator

9. Outgoing calls through GSM/UMTS

10. Incoming calls

11. Finish

3. Timezone

Select the applicable time zone. Setting the right time zone is important for the correct operation of time related features as well as call records. It also ensures correct switching of daylight-saving time.

Select timezone:

Fig. 3.3 – Configuration Wizard – Time zone

3. PIN Codes for SIM Cards

The following table lists the inserted SIM cards. If a SIM card requires a PIN code, it cannot be read until the PIN code has been entered. You will find the PIN code in the SIM card package that you received from your GSM provider. If no PIN code prompt appears for a SIM card, it is unnecessary to enter the PIN. After setting the PIN codes the gateway will restart. Please wait for the restart to complete and once again retrieve the set-up wizard page.



1. Introduction
2. Administrator's password
3. Timezone
- 4. PIN codes for SIM cards**
5. Data connection
6. Extension number allocation
7. Passwords for extensions
8. Outgoing calls through VoIP operator
9. Outgoing calls through GSM/UMTS
10. Incoming calls
11. Finish

4. PIN codes for SIM cards

Insert the SIM cards you want to use. The SIM card intended for UMTS data connection must be in position SIM1. If in the future you insert a different SIM card, it is always necessary to restart the equipment. Insert cards for GSM voice calls into the remaining positions.

The following table lists the inserted SIM cards. If a SIM card requires a PIN code, it cannot be read until the PIN code has been entered. You will find the PIN code in the package that the SIM card was supplied with from the operator. If no PIN code prompt appears for a SIM card, it is not necessary to enter one. After setting the PIN codes the gateway will restart. Please wait for the restart to complete and once again retrieve the setup guide page.

Module	SIM card number	Pin	Operator ID	Operator name
1	9420303102105		23003	Vodafone CZ
2	SIM card not found			
3	SIM card not found			

Fig. 3.4 – Configuration Wizard – PIN Codes

4. Data Connection

In this step you can set the data connection through the UMTS SIM card. Enter the APN, username and password for data connection if prompted by the network (you will find this information in the SIM card package, or call the provider's information line). If you cross the 'Automatic connection activation' checkbox, the Internet connection will always be active, even after a restart or temporary loss of power.



Caution

- The SIM card intended for UMTS data connection must be in the SIM1 position. If, in the future, you insert a different SIM card, it is always necessary to restart the equipment. Insert the cards for GSM voice calls in the remaining positions.



1. Introduction
2. Administrator's password
3. Timezone
4. PIN codes for SIM cards
- 5. Data connection**
6. Extension number allocation
7. Passwords for extensions
8. Outgoing calls through VoIP operator
9. Outgoing calls through GSM/UMTS
10. Incoming calls
11. Finish

5. Data connection

In this step you can set up the data connection through the UMTS SIM card. Enter the APN and username and password for data connection if prompted by the network (you will find this information in the package the SIM card came with, or by calling the operator information line). If you cross the box "Automatic connection activation", the Internet connection will always be active, even after a restart or temporary loss of power.

APN (access point):

Name:

Password:

Activate data connection automatically: ☐

Fig. 3.5 – Configuration Wizard – Data Connection

5. Extension Number Allocation

IP extensions can now be configured. Enter the number of the IP extensions that you want to establish automatically. The extensions will be assigned numbers 100, 101, 102... If you have the 2N® OfficeRoute version with an analogue line, it will have an analogue phone with number 199. After closing the wizard, you can still change the settings any time by going into 'User management'.




Fig. 3.6 – Configuration Wizard – Extension Number Allocation

6. Passwords for Extensions

When creating IP extensions remember to define a password to be used for IP phone configuring. The password will be displayed on the screen, so please take care to ensure the password security. After closing the wizard, you can change the password any time by entering 'User management'.




Fig. 3.7 – Configuration Wizard – Passwords for Extensions

7. Outgoing Calls through VoIP Provider

To use 2N® OfficeRoute for outgoing calls through a VoIP provider (it is necessary to have an allocated user account), enter the requested information as follows:



SIP server address - domain or IP address of the provider's SIP server;

SIP name - allocated phone number or account name;

User name - name for authentication (it can be the same as the SIP name);

Password - assigned password.

It is also necessary to specify the prefix for the call to be routed through the VoIP provider.

1. Introduction
2. Administrator's password
3. Timezone
4. PIN codes for SIM cards
5. Data connection
6. Extension number allocation
7. Passwords for extensions
- 8. Outgoing calls through VoIP operator**
9. Outgoing calls through GSM/UMTS
10. Incoming calls
11. Finish

8. Outgoing calls through VoIP operator

If you want to use 2N OfficeRoute for outgoing calls through the VoIP operator (it is necessary to have an allocated user account), enter in the requested information as follows: SIP server address = domain or IP address of the operator's SIP server; SIP name = allocated phone number or account name; User name = name for authentication (it can be the same as the SIP name); Password = assigned password. It is also necessary to specify the prefix on the basis of which a call will be routed through the VoIP operator.

Prefix 1

SIP server address:

SIP name:

Display name:

User name:

Password:

Description:

Fig. 3.8 – Configuration Wizard – SIP Provider

8. Outgoing Calls through GSM/UMTS

When making outgoing calls outside the office always start by dialling zero. If you have set the VoIP provider in the previous step, calls to numbers with no prefix will be routed through VoIP; all the other calls will be routed through the first vacant UMTS/GSM module.




Fig. 3.9 – Configuration Wizard – Outgoing Calls through GSM/UMTS

9. Incoming Calls

Select where incoming calls should be routed. If you select To DISA line, a welcome note will be played and the caller can choose an extension number. If you select To extension, incoming calls will be directed to the extension you have selected.




Fig. 3.10 – Configuration Wizard – Incoming Calls

10. Finish

2N® OfficeRoute is now ready for use.




Fig. 3.11 – Configuration Wizard – Finish



Note

- If you want to use the wizard again, you have to perform the 2N® OfficeRoute factory reset.

3.2 Web Access

Now that the initial wizard configuration is completed, you can configure all the gateway parameters using a web browser. To establish connection with the gateway, enter the gateway IP address into the Internet address setting line in the browser.

If you have connected all parts properly and set the correct gateway and PC IP addresses, the request to enter the access user name and password should get displayed.




Fig. 3.12 – Web Administration Login Page

By default, the username is Admin, Password is 2n.



Caution

- The manufacturer supplies the gateways with a predefined default IP address **192.168.1.1** and user account **Admin**, default password is **2n**. Mind the Upper/Lower Case while entering the user name and password!
- The first thing you should do for safety reasons after putting your gateway in operation is to change the administrator password

After a successful login you get onto the main page of the web application. The window is divided into four parts.



Fig. 3.13 – Web Interface Desktop

Header bar

Network, User management, Telephony services, Administration, States&Logs and Messaging. Use the tags above the header bar to select the user language and display the currently logged-in user.

Group menu

there is a group menu for each selection from the header bar on the left side. The tag settings are arranged in two menu levels. By selecting a Level 1 item you display the respective Level 2 subitems. If the Level 1 item contains no more subitems or if you select a subitem, the appropriate application form gets displayed on the remaining window space.

3.3 Survey of Group Tags and Menus

Network

IP address settings, DHCP server settings, Firewall settings, NATP settings, DNS proxy settings and HSPA/EDGE/GPRS (2N® OfficeRoute) or GPRS (2N® VoiceBlue Enterprise) data settings.

User management

User groups and user (extension) management.

Telephony services

Device (SIP, H.323, DISA lines) management, Fax, GSM incoming routing settings (provider/DISA), LCR settings, SIP proxy settings.

Administration

Main configuration, Time and Time zone settings, Firmware upgrade, Licence upload, Configuration back-up/restore, SNMP settings, Reboot.






States&Logs

States of devices and calls, Logs for debugging/troubleshooting, CDR.

Messaging

SMS delivery settings (web and SMTP/POP3), SMS sending web portal.

This is just a basic survey of menus. For details on forms, their meanings and options see later.

Parameters or new values can be added by clicking on the icon with a plus , modified by the pencil icon , reset by the  icon, removed by the icon with a red dart  and saved by clicking on the diskette icon .

3.4 Network Settings

Main Configuration

Includes 2N® OfficeRoute/2N® VoiceBlue Enterprise’s own IP address, mask, default gateway and DNS. There is also a possibility to switch on the DHCP client (when 2N® OfficeRoute/2N® VoiceBlue Enterprise does not serve as a DHCP server and there is another DHCP server in the network). It is also possible to select the main settings via a serial console or a Telnet console.

Main configuration

Filtering

Port mapping

DHCP server

DNS proxy

VRRP

Dynamic DNS

Data connection

SNMP

Modify network configuration

eth0

Enable DHCP:

☒

IP address:

192.168.200.3

Network mask:

255.255.255.0

Gateway:

192.168.200.1

DNS

Hostname:

voiceblue

DNS server 1:

192.168.200.1


DNS server 2:

0.0.0.0

Domain:

Fig. 3.14 – Main Configuration

Filtering

Embedded firewall settings. To add a new rule, click on the  icon. It is possible to set a rule for call accepting/barring according to the type of traffic, source or destination IP address or port. While creating more rules than one remember that these rules are searched from top to bottom.

Main configuration

Filtering

Port mapping

DHCP server

DNS proxy

VRRP

Dynamic DNS

Data connection

SNMP

Add network filter

Enabled:

☒

Protocol:

tcp

Action:

ACCEPT

Source IP address:

134.32.43.0/24

[!] address[/mask]

Destination IP address:

[!] address[/mask]

Source port:

80

[!] port[:port]

Destination port:

80

[!] port[:port]

Description:

Fig. 3.15 – Filtering


The form in Fig. 3.15 contains the following fields:

- **Protocol**
the protocol to be filtered.
- **Action**
you can accept or drop packets that are filtered.
- **Source IP address**
the IP address to be filtered.
- **Destination port**
the destination port to be filtered.
- **Description**
provides information on the rule.

Port Mapping

NATP setting for access devices in an internal LAN via the UMTS network (a public IP must be assigned to 2N® OfficeRoute/2N® VoiceBlue Enterprise by the provider). It is a transparent process where the network clients cannot see that port forwarding is being done. This process enables you to run a public Internet service on a machine that is otherwise hidden from the Internet by your gateway.

Example:



The screenshot shows a configuration window titled "Add port mapping". It contains the following fields and values:

Field	Value
Enabled:	<input checked="" type="checkbox"/>
Protocol:	tcp
Interface:	ppp0
Port:	80
New IP:	10.0.0.100:8088
Description:	Forwarding 80 to 8088

To the right of the "New IP" field, there is a label "address[:port]" indicating the format of the input.

Fig. 3.16 – Port Mapping

The configuration shown in Fig. 3.16 enables you to create a permanent translation entry that maps a TCP port 80 on your gateway to an IP address 10.0.0.100 and port 8088 on your private LAN.

DHCP Server

DHCP server settings in case 2N® OfficeRoute/2N® VoiceBlue Enterprise serves as a LAN DHCP server.

Fig. 3.17 – DHCP Server Setting Form

- **Lease time**
validity of a leased IP address in seconds.
- **Start address**
start of an IP address pool.
- **End address**
end of an IP address pool.
- **Subnet option**
subnet mask for an internal network.
- **Router option**
the default gateway of subnet (typically the 2N® OfficeRoute/2N® VoiceBlue Enterprise IP address, for VRRP it is the IP address of the virtual router).
- **Primary / Secondary DNS**
used only in the case of local DNSs in the LAN.

DNS Proxy

Used for caching DNS records in case 2N® OfficeRoute/2N® VoiceBlue Enterprise works as a UMTS/GPRS router. The DNS proxy can receive DNS queries from the local network and forward them to an Internet Domain Name Server. If the DNS Proxy is disabled, the gateway forwards all requests to the servers assigned by the UMTS (2N® OfficeRoute) or GPRS (2N® VoiceBlue Enterprise) provider.

The gateway can use the DNSs from the *Network settings* or you can forward the DNS queries to specified servers.

Fig. 3.18 – DNS Proxy Configuration

VRRP

The Virtual Router Redundancy Protocol is an Internet protocol, which provides a possibility to have one or more backup routers when using a statically configured router on a local area network (LAN). The most common arrangement is to specify one router to serve as the router for forwarding packets from a group of hosts on a LAN. If the router fails, however, there is no way to use another router as a backup.

Using VRRP, a virtual IP address can be specified manually or with the Dynamic Host Configuration Protocol (DHCP) by default. A virtual IP address is shared by the routers, with one designated as the master and the others as backups. In case the master fails, the virtual IP address is mapped to the backup router IP address (this backup thus becomes the master router).

The screenshot shows a web interface for configuring VRRP. On the left is a sidebar menu with options: Main configuration, Filtering, Port mapping, DHCP server, DNS proxy, VRRP (highlighted in orange), Dynamic DNS, Data connection, and SNMP. The main area is titled 'Modify configuration' and contains the following settings:

Field	Value
VRRP service enabled:	<input type="checkbox"/>
VRID:	1
Priority:	100
Advertisement interval:	1
Virtual router address:	10.0.0.254

Fig. 3.19 – VRRP Configuration

- **VRID**
provides virtual router identification. Must be unique for each virtual router.
- **Priority**
the higher the number, the lower the priority.
- **Advertisement interval**
indicates the time interval (in seconds) between advertisements. The default value is 1 second. This field is used for troubleshooting of misconfigured routers.
- **Virtual router address**
the IP address of a virtual router.

Dynamic DNS

The DDNS provides a gateway that has a variable, often changing IP address with a well-known hostname resolvable by network applications through standard DNS queries.

An example of use is a home user who wishes to access the computer on his or her home network while travelling. The user may be supplied with a different IP address whenever the Internet connection to the service provider is made, so there is no stable address to connect to. If the Dynamic DNS service is used to assign a fixed address to the device, then the user can, for example, establish a Virtual Private Network (VPN) to the network using that address. As a detailed example, the IP address can be 123.234.111.112 one day, 123.124.45.15 the next, but the Dynamic DNS address will always be, e.g. - office-route.dyndns.org.






Fig. 3.20 – Dynamic DNS Configuration

- **Hostname**
your hostname registered with a DDNS provider.
- **System**
choose your DDNS provider from the list of supported DDNS providers.
- **Username**
enter your username in accordance with your DDNS account.
- **Password**
enter your password in accordance with your DDNS account.
- **Update period**
the period of IP address updating at the DDNS server.
- **HTTP proxy**
enter the IP address of your HTTP proxy. If you have no HTTP proxy, leave the field blank.

Data Connection

In this menu you can see the list of inserted SIM cards and start/stop data connection by clicking on the  icon.




Connection provider name	GSM module	Dial number (optional)	APN (access point)
Data_on_SIM_94203031021050	1	Internet	

Fig. 3.21 – Data Connection – SIM Cards

To modify the data connection settings click on the pencil icon.

Modify SIM card number
"94203031021050"

SIM card parameters

Present: ☒

SIM card number: 94203031021050

Operator ID: 23003

Operator name: Vodafone CZD

USSD code for credit:

Last USSD message:

Last USSD message timestamp:

Description:

SMS settings

Service Center Number: +420608005681

Data connection

Connection provider name: Data_on_SIM_9420303

Dial number (optional):

APN (access point): Internet

Initial AT commands (optional):

PPP username (optional):

PPP password (optional):

[Clear data config](#)

Fig. 3.22 – Data Connection – Modify SIM Card Form



Note

- You are strongly recommended to power off the unit before inserting/removing the SIM card.

Modification of SIM card parameters:

- **Present**
the checkbox indicates whether the SIM is present in the tray at the moment.
- **SIM card number**
information on the SIM serial number (IMSI).
- **Provider ID**
the provider's network code.
- **Provider name**
the provider's name.
- **USSD code for credit**
here you can fill in the USSD code for credit check for your prepaid SIM cards. If you fill in the proper USSD code and the SIM card is prepaid, you can obtain credit information by clicking on *Get credit* in the SIM cards list.
- **Last USSD message**
shows the last obtained USSD message.

- **Last USSD message time stamp**
shows the last USSD message timestamp.
- **Description**
user description of the SIM card.
- **Service Centre Number**
enter the service centre number. It is necessary for SMS sending.
- **Connection provider name**
enter any name. This field is compulsory.
- **Dial number (optional)**
the number to be dialled for data connection
- **APN (access point)**
this field is compulsory. Complete it in accordance with your provider's APN name.
- **Initial AT commands (optional)**
an optional field. You can define here a special AT command for Internet connection.
- **PPP username (optional)**
an optional field. Enter your PPP user name if it is recommended.
- **PPP password (optional)**
an optional field. Enter your PPP password if it is recommended.

In order to use the SIM for data/Internet connection (for GPRS/EDGE/UMTS/HSPA) you have to set the **Connection provider name and APN** parameters. The other parameters depend on the network provider's data. To obtain the data, refer to your network provider's websites or call the provider's helpline.

SNMP

The Simple Network Management Protocol (SNMP) daemon is a background server process that can be run on any Transmission Control Protocol/Internet Protocol (TCP/IP) workstation host. It helps you monitor the state of the device on the network.

Main configuration

Filtering

Port mapping

DHCP server

DNS proxy

VRRP

Dynamic DNS

Data connection

SNMP

- Switch SNMP daemon on

SNMP daemon configuration

IP address for SNMP traps: 10.0.0.254

Community: public

Traps enabled:

Calls: ☐

LCR: ☐

GSM: ☐

Fig. 3.23 – SNMP Configuration

IP address for SNMP traps

the IP address to which traps are sent.

Community

a group to which the devices and management stations running SNMP belong. Helps you define where information is sent. The default SNMP communities are:

Write = private

Read = public

Traps enabled

you can enable traps for Calls, LCR and GSM.

3.5 User Management

Users

In this menu you can see a list of all users and the Add/Remove user item. A user is either an extension or a user allowed to send SMS. A user may log in to the gateway and make some changes (send SMS) according to the rights assigned. If a line number is assigned to a user, the user is an extension at the same time.


<div>Users</div> <div>Groups</div> <div>Ring groups</div>	Users							
	Name	Group	Language	Line number	Description			
	10	SMS	English	10				
	11	SMS	English	11				
	Admin	Administrators	English		Administrator			

Fig. 3.24 – List of Available Users

Admin is the default user and cannot be removed. It is primarily used for device management.

Emergency change of *Admin* password – if you are connecting 2N® OfficeRoute/2N® VoiceBlue Enterprise via a USB cable or a serial console change the Admin password (it is not necessary to know the old one).

Add User

To add a new user/extension click on the Add user  icon in the right-hand bottom corner.

Add user

User name: 100

New password: jakok

Confirm new password: jakok

Group: Administrators

Language: Slovensky

Default application: User management

Rights: ☐ USERS+LINES+LCR ☐ USERS ☐ LINES ☐ LCR ☒ SMS

Rights denied: ☒ USERS+LINES+LCR ☐ USERS ☐ LINES ☐ LCR ☐ SMS

Line number: 100

Description:

Mobility Extension

Outgoing ME enabled: ☒

Outgoing ME number: 603303404

Incoming ME enabled: ☒

Incoming ME number: 603303404

Voicemail

Voicemail enabled: ☒

PIN: 1234

SMS notification number: 603303404

Fig. 3.25 – Add User Form

- **User name**
the user name for login to 2N[®] OfficeRoute web interface and SIP authentication.
- **New password**
the password for login and SIP authentication.
- **Group**
select the user group.
- **Language**
select the default language for the user.
- **Default application**
the webpage/form after login to 2N[®] OfficeRoute web interface.
- **Rights/Rights denied**
select rights or leave empty – the rights are assigned by group selection except for the SMS rights.
- **Line number**
in case the user is both extension and user, the *Line number* is UID (number of extension/SIP name).
- **Mobility Extension**
in case you need to set the *Mobility Extension* for this user, tick off the *Outgoing/Incoming ME* checkbox and fill in the user's mobile phone number.
- **VoiceMail**
set the PIN for entering the user VoiceMail and enter the user's mobile phone number for receiving notification SMS.

Groups

Groups are created to eliminate the need to specify access rights for each user individually. Upon login, the resultant set of assigned and barred rights consists of the selected rights group settings and, if necessary, corrections made during the user account creation.

Users

Groups

Ring groups

Groups

Name	Description			
Administrators	Group for administrators			
SMS	only for sms			

Fig. 3.26 – List of Available Groups

Administrators

is a group with all rights enabled.

SMS

is a group with the SMS rights enabled only.

Add Group

To add a new group click on the Add group  icon in the right-hand bottom corner.

Add group

Group name:

Rights: ☐ USERS+LINES+LCR ☒ USERS ☐ LINES ☐ LCR

Rights denied: ☐ USERS+LINES+LCR ☐ USERS ☒ LINES ☒ LCR

Description:

Fig. 3.27 – Group Adding Form

The form in Fig. 3.27 contains the following fields:


- **Group name**
a unique identifier.
- **Rights**
parts of the system to be made available.
- **Rights denied**
parts of the system to be barred.
- **Description**
any text that describes the meaning of a group.

The web interface is divided into parts to/from which access rights can be assigned/removed. The checkboxes in the above-mentioned forms, one pair per group, are used for right group and user account setting. They are as follows:

- **USERS+LINES+LCR**
the whole system.
- **USERS**
definition of the user accounts and groups.
- **LINES**
communication line settings.
- **LCR**
the Least Cost Router configuration.

Ring Groups

To add a ring group click on the Add group  icon in the right-hand bottom corner.



Extensions:	Group member	Mobility extension
11	<input checked="" type="checkbox"/>	<input type="checkbox"/>
12	<input checked="" type="checkbox"/>	<input type="checkbox"/>
13	<input type="checkbox"/>	<input type="checkbox"/>

Fig. 3.28 – Ring Group Adding Form

Tick off the checkboxes to assign the extensions and their Mobility Extension numbers to the members of a new ring group.

3.6 Telephony Services

Before the description of all items of the Telephony services menu, a short introduction about the VoIP Network Arrangement and Routing behaviours is given there.

VoIP Network Arrangement

VoIP telephony communication has two components – signalling and voice. Signalling is primarily used for establishing and terminating calls, telephone login to a PBX, negotiating parameters and control of the speech/voice channel. The voice channel is only used for transmission of encoded digitised voice information.

Typically, VoIP telephones are operated together with a PBX, which coordinates their traffic. For a schematic arrangement see fig.39. The VoIP telephony PBX is a software application that looks like a traditional PBX. Its functions include mainly numbering plan consistence maintenance, routing, user or telephone rights, call billing, call forwarding, DISA, etc. But it can integrate more functions, e.g. voicemail. SIP telephone PBXs are usually called SIP proxies while PBXs for H.323 are called gatekeepers.




Fig. 3.29 – VoIP PBX Arrangement

To work properly, a VoIP PBX must process all signalling traffic. Unlike this, voice channel data are transmitted directly between the terminal points. This is, among others, a difference from the model described below. It is because a PBX is not necessarily required in the IP telephony. Signalling protocols are designed in such a manner that it is possible to call from one terminal to another directly, without any mediator. To do this, you have to know the full ID of the terminal to be called, i.e. also the IP address and destination port, of course. This is the main disadvantage compared with the preceding model for multiple-telephone locations.




Fig. 3.30 – "Point-to-Point" Arrangement

If you use a PBX, the terminal points must know the PBX address only. The PBX is able to route requests according to information acquired in the process of telephone login to the PBX. With the "Point-to-Point" arrangement, all telephones must be equipped with information on surrounding telephones. This model is mostly applied in direct calling via the Internet where you do not want or cannot use services of any telecom provider. The 2N® OfficeRoute/2N® VoiceBlue Enterprise gateway is capable of working in both the types of environment, with a PBX and without a PBX.




Fig. 3.31 – VoIP-to-GSM Gateway with PBX

It can even replace the PBX completely for SIP telephones because it is equipped with an integrated SIP proxy. This simplifies the VoIP network structure as shown in Fig. 3.32.




Fig. 3.32 – 2N® OfficeRoute as SIP Proxy

Although call interconnection between VoIP and GSM networks is the primary function of 2N® OfficeRoute/2N® VoiceBlue Enterprise, the gateway can also be used for bridging VoIP networks with different signalling standards – SIP and H.323. For such arrangement see Fig. 3.33.




Fig. 3.33 – 2N® OfficeRoute as SIP - H.323 Gateway

The situation shown in fig. 43 differs from simple SIP-based call connection in that the gateway transmits both signalling and voice channels here, like in interconnecting calls from VoIP to GSM. This results in a certain limitation of the maximum number of calls due to a limited hardware pass-through capacity of the gateway.

Routing

Routing means a process of retrieving a route from the calling party to the called one. There are various routing methods according to the type of call and place from which the call is coming.

Within VoIP Network

Speaking of routing within a single VoIP network, we think of the activity executed by the PBX whenever a registered user initiates a new call. The result of this process is a route to another registered user based on the called number analysis. The called number can be an IP telephone, GSM gateway, PSTN gateway, another VoIP PBX, etc.




Fig. 3.34 - Call Routing by VoIP PBX

The routing options are dependent on the capabilities of the particular PBX. For SIP-based telephones, a SIP proxy server built in 2N® OfficeRoute/2N® VoiceBlue Enterprise can be used as a PBX.

From VoIP to GSM

On coming to an 2N® OfficeRoute/2N® VoiceBlue Enterprise VoIP line, a call proceeds to the Least Cost Router (LCR). The LCR decides which line the call shall use for going out. The decision depends on the called number and LCR settings.




Fig. 3.35 - Routing of Incoming Calls from VoIP

Although the Least Cost Router is, as its name suggests, designed primarily for searching the most cost-efficient route to a GSM network, it is not limited just to this function. Generally, it can interconnect incoming calls from VoIP lines to any lines that are available in the gateway regardless of their types. This is very useful for interconnecting heterogeneous VoIP networks, such as SIP and H.323 environments.

Incoming Calls from GSM

A special routing mechanism is applied to calls coming to the 2N® OfficeRoute/2N® VoiceBlue Enterprise gateway from GSM networks.




Fig. 3.36 - Routing of Incoming Calls from GSM

As selected, the GSM router:

- 1) forwards the call to a fixed operator;
- 2) plays ME message and allow to dial local or remote number according to the ME CLIP; or
- 3) forwards the call to the DISA automat where the calling party chooses the route using a voice menu and tone dialling.

Since incoming calls from GSM networks can only be routed to VoIP lines in the gateway it is impossible to connect a call back to the GSM network in this type of routing. This, however, does not mean that this operation cannot be executed on another routing level, e.g. in a PBX.

If the VoIP telephones used are equipped with the Calling Line Identification Presentation (CLIP) function, either the internal number of the gateway output line used for the incoming GSM call, or the CLIP obtained from the GSM network can be displayed. This VoIP line parameter is set at the first option by default. To make the gateway convey a public number to the VoIP telephone it is necessary to ensure that all routing elements be able to process the CLIP correctly in the opposite direction.

Devices

Call interconnecting and routing in 2N® OfficeRoute/2N® VoiceBlue Enterprise takes place between lines. This means that where no line is available the gateway cannot set

up a call. Nevertheless, the notion 'line' is less materialistic in VoIP gateways than in classical telephone systems.

To make some equipment work as a gateway, another line at least has to be created to the VoIP environment. This line is either used for the gateway - VoIP PBX connection or a direct gateway - VoIP telephone connection. From the viewpoint of the network environment of the gateway, a VoIP line represents a virtual VoIP telephone set.

It is possible to define more VoIP lines than one in the gateway. Then the gateway appears like a system of multiple virtual VoIP telephones. All line types are equal for the routing and connecting purposes.

SIP Lines

One or more lines can be defined in 2N® OfficeRoute/2N® VoiceBlue Enterprise for communication with some other SIP using VoIP equipment. Each line has a unique number and receiving UDP port. You can register the line at the SIP proxy or communicate directly with another VoIP terminal. The registration can be either anonymous or related to the gateway authentication.

By default an internal SIP line is prepared. This line is necessary for you to make calls out of the SIP proxy.

SIP lines						
Line ID	SIP server	Phone number	Description			
[19]	10.0.3.100	My_SIP_Name	Line to my SIP operator	⚡	✗	<input type="checkbox"/>
[16]	10.0.0.1	vbegw		⚡	✗	<input type="checkbox"/>

Fig. 3.37 – List of SIP Lines

Modify SIP line

To make calls out of the SIP proxy you have to modify the internal SIP line ID [16]. To make a trunk to a VoIP provider create a new SIP line.

Modify SIP line ID "16"

SIP server address:	<input type="text" value="10.1.1.10"/>	
SIP domain:	<input type="text"/>	
SIP name:	<input type="text" value="vbegw"/>	
Display name:	<input type="text"/>	
Listen port:	<input type="text" value="5061"/>	If exists SIP proxy registration, listen port cannot be 5060
User name:	<input type="text"/>	
Password:	<input type="text"/>	
Codecs:	<input type="text" value="G.711 A Law 64000 bps"/> <input type="text" value="G.711 u Law 64000 bps"/> <input type="text" value="G.729 8000 bps"/>	<input type="button" value="Shift up"/> <input type="button" value="Shift down"/>
Add Phone context to REGISTER request:	<input type="text"/>	
Register expires (seconds):	<input type="text" value="300"/>	
Register with proxy:	<input type="checkbox"/>	
Enable CLIP:	<input checked="" type="checkbox"/>	
Allow only one call:	<input type="checkbox"/>	
Get callee from:	<input type="text" value="Request URI"/>	
Enable NAT:	<input type="checkbox"/>	
NAT port begin:	<input type="text" value="0"/>	
NAT port range:	<input type="text" value="0"/>	
NAT IP address:	<input type="text"/>	
No route code:	<input type="text" value="0"/>	
SIP TOS/DiffServ Value:	<input type="text" value="0x68"/>	
RTP TOS/DiffServ Value:	<input type="text" value="0xb8"/>	
Description:	<input type="text" value="Internal SIP line"/>	

Fig. 3.38 – Modify Internal SIP Line

- **SIP server address**
change the default IP to the IP that is used for the IP module. While creating a new line, enter the IP address of your VoIP provider.
- **SIP domain**
it is not necessary for the internal SIP line.
- **SIP name**
the internal SIP line SIP name is '1111'. For a new line enter the SIP name according to your VoIP provider.
- **Display name**
the line name to be displayed. An optional parameter.
- **Listen port**
each line has to use a different listening port.
- **User name**
is unnecessary for the internal SIP line and may be deleted. For a new line enter the user name according to your VoIP provider.

- **Password**
is unnecessary for the internal SIP line and may be deleted. For a new line enter the password according to your VoIP provider.
- **Codecs**
this parameter is necessary to highlight the codecs to be used. You can shift the codecs to define their priority.
- **Add Phone context to REGISTER request**
this can be useful in some special cases. Mostly it is unnecessary to fill in this item.
- **Register expires**
enter the value according to your VoIP provider. Unnecessary for the internal SIP line.
- **Register with proxy**
unselect this checkbox for the internal SIP line. For a new line check it according to your VoIP provider.
- **Enable CLIP**
select this checkbox for the internal SIP line.
- **Allow only one call**
unselect this checkbox for the internal SIP line.
- **Get callee from**
this can be useful in some special cases. Mostly it is unnecessary to change these settings.
- **Enable NAT**
check this item in case the VoIP module is behind the NAT or firewall.
- **NAT port begin**
set which port will be used first for the RTP protocol.
- **NAT port range**
set how many ports will be used for RTP packets.
- **NAT IP address**
the public IP behind the PBX VoIP module.

H.323 Lines

Another signalling standard supported by the IP telephony is a group of protocols called H.323. It could be set only one H.323 line, but it can transfer more calls at the same time. This line can log in to the Gatekeeper or communicate directly with VoIP telephones or other gateways.

Modify H.323 line ID "24"

Call method:	Gateway
Gatekeeper discovery method:	Discover Gatekeeper automatically (use multicast)
Gatekeeper address:	
Gateway address:	
Gateway prefix(es):	
Endpoint type:	Gateway
Display name:	
Numbers:	
Listen port:	1720
Disable Fast start:	<input type="checkbox"/>
Disable H.245 tunneling:	<input type="checkbox"/>
DTMF type:	Signal
Codecs:	<div> G.711 A Law 64000 bps G.711 u Law 64000 bps G.729 8000 bps </div> <div> Shift up Shift down </div>
Rejected call code:	Local endpoint application cleared call
No route code:	Local endpoint application cleared call
RTP TOS/DiffServ Value:	0xb8
Description:	

Fig. 3.39 – H.323 Line Details

The form contains the following fields:

- **Call method**
defines how to initiate a new call. There are three options:
 1. *Direct* – calling including identification of the fully qualified network name of the called line;
 2. *Gatekeeper* – the selected Gatekeeper shall find the route and set up a call;
 3. *Gateway* – calling via a selected gateway.
- **Gatekeeper discovery method**
defines how to find the available Gatekeeper address. The address can be entered statically or determined by network retrieval.
- **Gatekeeper address**
if not determined by network retrieval, the Gatekeeper address must be entered in this field.
- **Gateway address**
the address of the gateway to be used for calling if the *Gateway* calling method is selected.

- **Gateway prefix(es)**
the prefixes used by the gateway for registration.
- **Endpoint type**
the gateway can register itself to the Gatekeeper either as a gateway for a prefix (destinations starting with the prefix are routed through the gateway) or as a terminal (virtual telephone).
- **Display name**
the text to be displayed to the called line.
- **Numbers**
numbers of the line working in the terminal mode.
- **Listen port**
the TCP port on which the line receives H.323 connections.
- **Disable Fast start**
the Fast start method provides a faster start of the voice stream while a new H.323 connection is being set up.
- **Disable H.245 tunnelling**
disallows the use of H.245 tunnelling.
- **Disable Early media start**
disallows the use of the Early media start method. This method establishes the voice channel before the call has been set up completely. It is useful for transmission of the so-called 'progress tones' from the GSM network.
- **DTMF type**
choose the set of supported DTMF tones; either numbers only (the *Signal* option) or all alphanumeric characters (the *Alphanum* option).
- **Codecs**
a list of codecs to be provided by the gateway for voice channel negotiations.
- **Rejected call code**
the code that the gateway returns back to the Gatekeeper/gateway in the case of rejected call.
- **No route code**
the code that the gateway returns back to the Gatekeeper/gateway in case no route (no GSM module/SIP line/H.323 line/SIP phone) is ready for a call. This is used mainly for overflow/emergency routing.
- **Description**
any text that describes the meaning of the form.

SIM Cards

If you operate the gateway with different providers' SIM cards, you will definitely want to use a GSM provider's SIM card for GSM call routing. When a new SIM card is inserted, the gateway creates automatically a 'SIM card – xxx' line where xxx is the SIM card ID (typically printed on the card next to contacts). The physical location of the SIM card does not matter in call connection.



Note

- You are strongly recommended to power off the unit before inserting/removing the SIM card.

Each SIM card inserted in the gateway has a set of parameters of its own. Their values are bound to the card ID and remain stored in the gateway even after the SIM card is removed. Thus, if the SIM card is reinserted, the parameters need not be reset. The list of cards with available configuration parameters is displayed in a table on the introductory page of the SIM card configuration.

Devices <ul style="list-style-type: none"> ▪ SIP lines ▪ H.323 lines ▪ SIM cards ▪ DISA lines ▪ Fax lines ▪ Fxs line GSM Services Mobility Extension Fax		SIM cards						
Present in module	SIM card number	Operator ID	Operator name	Last USSD message	Description			
1	94200110453871	23001	T-Mobile CZ					Get credit USSD
2	94203031021050	23003	Vodafone CZ					Get credit USSD

Fig. 3.40 – List of Available SIM Cards

In this menu (Fig. 3.40) you can see the list of inserted SIM cards and also get the credit on each SIM card. For this function it is necessary to define the USSD code for getting information on the SIM card credit. The code syntax depends on the provider.

The columns in Fig. 3.40 include:

- **Present in module**
a mark that the SIM card has been inserted in the gateway.
- **SIM card number**
a unique card identifier. It is usually printed on the card next to contacts. By clicking on the number you display the card setting detail.
- **Provider ID**
a mobile network provider's identifier.
- **Provider name**
a mobile network provider's name.
- **Description**
a text entered by the administrator.

By clicking on the pencil symbol you get into the line setting detail and can change the settings. The cross is used for deleting a line.

Modification of SIM Card Parameters

Modify SIM card number
"94203031021050"

SIM card parameters

Present: ☒

SIM card number: 94203031021050

Operator ID: 23003

Operator name: Vodafone CZD

USSD code for credit:

Last USSD message:

Last USSD message timestamp:

Description:

SMS settings

Service Center Number: +420608005681

Data connection

Connection provider name: Data_on_SIM_9420303

Dial number (optional):

APN (access point): Internet

Initial AT commands (optional):

PPP username (optional):

PPP password (optional):

[Clear data config](#)

Fig. 3.41 – Data Connection – Modify SIM Card Form

- **Present**
indicates whether the SIM is present in the tray at the moment.
- **SIM card number**
information on the SIM serial number (IMSI).
- **Provider ID**
the provider's network code.
- **Provider name**
the provider's name.
- **USSD code for credit**
here you can also enter the USSD code for credit check for prepaid SIM cards. If you fill in the proper USSD code and the SIM card is prepaid, you can obtain credit information by clicking on 'Get credit' in the SIM card list.
- **Last USSD message**
shows the last obtained USSD message.
- **Last USSD message timestamp**
shows the last USSD message timestamp.
- **Description**
user description of the SIM card.

- **Service Centre Number**

enter the Service centre number. It is necessary for SMS sending.

In order to use the SIM for data/Internet connection (for GPRS/EDGE/UMTS/HSPA - 2N® OfficeRoute or GPRS - 2N® VoiceBlue Enterprise), you have to set the **Connection provider name and APN** parameters. The other parameters depend on the network provider – for information refer to your network provider's websites or call the provider's helpline.

- **Connection provider name**

it can be any name. This field is compulsory.

- **Dial number (optional)**

the number to be dialled for data connection.

- **APN (access point)**

this field is compulsory. Complete it in accordance with your provider's APN name.

- **Initial AT commands (optional)**

an optional field. You can define here a special AT command for Internet connection.

- **PPP username (optional)**

an optional field. Enter your PPP user name if recommended.

- **PPP password (optional)**



an optional field. Enter your PPP password if recommended.

DISA Line

The DISA line can be a standard welcome note or a customised welcome note, VoiceMail system and basic IVR. The DISA line is used for incoming calls, mostly from a GSM network. It might also serve for incoming calls from the VoIP provider.



The DISA line plays a message/dial tone and then waits for DTMF dialling. After receiving a hash (#), it dials the collected digits via a predefined SIP line.



The initial screen of the DISA line configuration shows a table of defined lines.

Click on the pencil icon  to move to the line setting detail for changes. The  symbol serves for line clearing.

Below the table there is an Add DISA service line  icon. Click on it to display the line defining form. There are also Upload custom DISA messages  DISA, Upload DISA/IVR package to internal Flash  and Upload VoiceMail language pack  icons.

DISA Line Parameters

To add a new line, use the Add  icon below the form. To modify an existing line, click on the Modify  icon. Upon the click, the entered data are confirmed and the execution of the relevant operation is requested.

Below the form there are Reset  and Back  icons. The first one restores the values of all fields as before the form opening and the other moves you to the previous screen.




Fig. 3.42 – DISA Line

The form in Fig. 3.42 contains the following fields:

Type of DISA

there are five options:

- **Basic DISA**
the factory-set DISA message.
- **Basic DISA with uploaded message**
the basic DISA message.
- **DISA/IVR on MMC card**
the DISA message saved in an external memory.
- **DISA/IVR on internal flash**
DISA message saved on the internal flash memory.
- **VoiceMail system**
the VoiceMail voice menu.

Maximum allowed number of digits

the maximum number of digits in DISA.

Description



any text that describes the meaning of a line.



Note

- For examples of DISA settings refer to faq.2n.cz

Fax Lines

To add a new fax line use the Add  icon below the form. To modify an existing line click on the Modify  icon. Upon the click, the entered data are confirmed and the execution of the relevant operation is requested.




Fig. 3.43 – FAX Line

The form in Fig. 3.43 contains the following fields:

- **Fax device**
choose a GSM module with an inserted SIM with the FAX service and fill in the SIM fax number.
- **Fax number**
the Fax line number.
- **Description**
any text describing the meaning of an item.



Note

- For examples of FAX settings refer to faq.2n.cz



Note


- The Fax line is implemented only with 2N® OfficeRoute

Fxs Line



Note

- The Fxs line is implemented only with 2N® OfficeRoute

This line is set by the wizard. To change some parameters, click on the Modify  icon.

Devices <ul style="list-style-type: none">▪ SIP lines▪ SIM cards▪ DISA lines▪ Fax lines▪ Fxs line	Fxs line			
	Line ID	Fxs number	Description	
	[17]	19		

Fig. 3.44 – Fxs Line

Modify fxs line ID "17"

Fxs number:

19

Dial timeout:

35

Ring timeout:

35

Enable line reversion:

☐

Enable '#' as dial end:

☒

Description:

Fig. 3.45 – Fxs Line - Modify

The form in Fig. 3.45 contains the following fields:

- **Fxs number**
the Fxs line number.
- **Dial timeout**
the first digit dialling timeout.
- **Ring time**
the Fxs line ringing time for incoming calls.
- **Enable line reversal**
polarity reversal at the call beginning and end.
- **Enable '#' as dial end**
you can use a hash as the end of dialling character.
- **Description**
any text that describes the meaning of an item.
-

GSM

PINs

In this menu you can define the PIN code for each SIM card.

Devices

- GSM
 - PINs**
 - Audio parameters
 - CLIPs
- Mobility Extension
- Fax

PINs

PIN for SIM card in module 1:

PIN for SIM card in module 2:

PIN for SIM card in module 3:

PIN for SIM card in module 4:

Fig. 3.46 – GSM - PINs

Audio Parametres

You can define the microphone gain and the speaker gain for each module. The range is from -24dB to 42dB with a 1dB step.

Devices

- GSM
 - PINs
 - Audio parameters**
 - CLIPs
- Services
- Mobility Extension
- Fax
- LCR
- GSM routing
- SIP proxy

Audio parameters

Microphone gain - module 1: dB, range -24dB to 12dB, step 1dB

Microphone gain - module 2: dB, range -24dB to 42dB, step 1dB

Microphone gain - module 3: dB, range -24dB to 42dB, step 1dB

Microphone gain - module 4: dB, range -24dB to 42dB, step 1dB

Speaker gain - module 1: dB, range -24dB to 12dB, step 1dB

Speaker gain - module 2: dB, range -24dB to 0dB, step 1dB

Speaker gain - module 3: dB, range -24dB to 0dB, step 1dB

Speaker gain - module 4: dB, range -24dB to 0dB, step 1dB

Fig. 3.47 – GSM – Audio Parametres

CLIPs

You can define the CLI function (CLIP - Calling Line Identification Presentation, or CLIR - Calling Line Identification Restriction) and also set the Auto CLIP routing in this menu.

Auto CLIP Routing

The AutoClip routing is used for automatic routing of incoming calls to internal extensions. Records are added to the gateway memory while outgoing calls are made and stored for a defined time. When an internal extension makes an outgoing call and the Auto CLIP routing is enabled, the new records on the calling and called numbers are saved into the internal memory. If the called number calls back in a defined time, the call is automatically routed to the internal extension that was the first to call this number.

Fig. 3.48 – GSM – CLIPs

The form in Fig. 3.48 contains the following fields:

Original CLI support

check this option to enable the CLI support.

Auto CLIP routing

check this option to enable the Auto CLIP routing function.

-expiration time

enter the number of hours for which the records shall be saved.

-delete record after anter

check this option to delete a record in the CLIP routing memory after a successful call.

-add only missed calls

check this option to add missed calls only to the memory.

-look up both lists (call & sms)

enables the Auto CallBack function after a call or after SMS sending.

Disable GSM alerting detection

if ticked off, the gateway does not detect alerting and sends the session progress tone immediately.

Services

Services provide to enable/disable ME by sending SMS. The SMS has to be send from ME user's number filled in the user settings.

To enable ME function, just send SMS to gateway: *<Service code>

To disable ME function, send: #<Service code>

The gateway responds responds with a confirmation SMS.

Service name	Service code
Outgoing ME enabled:	44

Fig. 3.49 – Services

Mobility Extension

The Mobility Extension (ME) is a 2N® OfficeRoute/2N® VoiceBlue Enterprise feature that makes internal extensions available on mobile phones. Remember to define the Mobility Extension number in the user settings. For the global settings of this function see Fig. 3.49.

Mobility Extension	
Outgoing ME enabled:	<input type="checkbox"/>
Incoming ME enabled:	<input type="checkbox"/>
Mobility extension SIP route:	10.0.0.1:5061
Mobility extension DISA line:	<input type="text"/>

Fig. 3.50 – Mobility Extension

The form in Fig. 3.49 contains the following fields:

- **Outgoing ME enabled**
check this option to enable the Mobility Extension function for outgoing calls.
- **Incoming ME enabled**
check this option to enable the Mobility Extension function for incoming calls (calls from the Mobility Extension numbers defined in the user settings).
- **Mobility Extension SIP route**
define which route shall be used for the outgoing ME calls.
- **Mobility Extension DISA line**
the DISA message for outgoing calls.



Note

- For examples of Mobility Extension settings refer to faq.2n.cz


Fax

■



Note

- The configuration of Fax is implemented only with 2N® OfficeRoute

2N® OfficeRoute/2N® VoiceBlue Enterprise also provides the FAX function, supporting T.38. To change some T.38 fax relay parameters, click on the Modify  icon.





Fig. 3.51 - T.38 Fax Relay Settings

The form in Fig. 3.51 contains the following fields:

- **Maximum fax rate**
the FAX bit rate for T.38 [bit/s].
- **T.30 message redundancy**
signalling redundancy.
- **Image data redundancy**
image redundancy.

LCR

The Least Cost Router (LCR) is 'the brain' of 2N® OfficeRoute/2N® VoiceBlue Enterprise. All call routing rules (inbound and outbound) can be set there.



The purpose of the Least Cost Router is to find the optimum output line for the called number. The LCR process has several stages:

Input normalisation

the calling and called line numbers are transformed into a normalised format before entering the LCR.

Destination searching

a destination means the target party to the call. The destination includes a group and type of line searching in the group. The group is searched according to the prefix of the normalised called number.

Group searching

a group means a logical set of lines. The group definition includes a route time limit within a week.

Line searching

a route can consist of one or more lines. The final line is determined according to the selected line selection algorithm. Three ways of searching are available:

- 1 *First free line* – finds the first free line;
- 2 *Cycle* – selects the free line with the earliest time of the last call; and
- 3 *Free minutes* – uses the free line with the highest number of remaining free minutes. Correct tariff rates must be selected for the lines for the method to work effectively.


Output normalisation

the calling and called line numbers are transformed into a normalised format before the call is forwarded to the output line.

Check for barred numbers

the Barred numbers table is searched for match after output normalising and before forwarding to the successfully found output line, and, if a match is found, the call is rejected.

By default, the LCR connects all VoIP calls to the VoIP module without modifying the called number.










Destination	Prefix	Enabled	Routes
GSM	0; 00420	<input checked="" type="checkbox"/>	GSM out
Voicemail	888	<input checked="" type="checkbox"/>	VM

Fig. 3.52 - List of LCR Rules

Routing Rules

The routing rules are the core of the LCR system. They consist of a relatively high number of parameters, which make the routing process highly flexible. A guide is available to make your configuration steps as convenient as possible.

Start with clicking on the *LCR* item in the *Telephony services* tag menu. A table gets displayed with predefined routing rules and buttons that help you Add new items , Shift up , Shift down , Insert before , Insert after , Modify  and Remove  the existing rules.

All the above-mentioned buttons except for *Add* are inactive in the initial status (greyish). They will not become active until one routing rule at least is selected by putting the checkmark in the second column of the respective line. By pushing the button activated in this way you get executed the operation above the routing rules selected.

Add rule

to open the routing rule adding form click on the Add or Insert after or Insert before key. The guide will appear in a new window.

The first step is to define the destination. Basically, the destination is a set of prefixes. Looking for the appropriate routing rule, the LCR searches the allowed routing rules from top to bottom for a match between the normalised called number prefix and the destination number prefix. The first matching prefix stops the searching process and the call is routed according to the respective destination rule.




Fig. 3.53 - LCR – Add Rule

The form contains the following fields:

- **Enabled**
a routing rule can be defined yet need not be used in the routing process. Enabled rules are used only.
- **Destination name**
the destination must be named briefly and clearly, e.g. according to the mobile network provider or any other characteristic feature that distinguishes the destination from the others. The name may contain alphanumerical characters only.
- **Prefix n**
the destination prefix where **n** is a serial number. The prefix is a beginning of the target telephone number. If you leave the first prefix blank and do not enter any other, then the particular destination includes all called numbers. To enter more prefixes, add new items by pressing the Add others key.
- **Description**
any text that describes the meaning of a destination.
- **Route name**
the outgoing route for prefixes of the destination. You can also add a new route if necessary.
- **Priority type n**
the priority for the lines defined in the chosen route.
- **Description**
any text that describes the meaning of a rule.

Time Intervals

There is a possibility to define the time interval (condition) for using a LCR route. The default time intervals are 'weekdays', 'weekend' and 'workdays'. It is also possible to define a certain time range.

Time intervals

Day groups

Name	Sun	Mon	Tue	Wed	Thu	Fri	Sat			
weekdays		All day	All day	All day	All day	All day				
weekend	All day						All day			
workdays		07:00 17:00	07:00 17:00	07:00 17:00	07:00 17:00	07:00 17:00				

Time ranges

No time range present

Fig. 3.54 - Time Intervals

Normalisation

When we introduced the LCR operations, we mentioned modifications of numbers before input into and after output from the routing process – so-called normalising. Normalising means conditioned transformations of the called and/or calling numbers into a unified format, which facilitates definition of the routing rules. The normalising regulation is determined by the following three parameters:

- **Normalising type**
defines at which process stage (input/output) and for which numbers (called/calling) normalising should be used.
- **Condition**
transformation is only applied to numbers that meet a condition. The condition is specified by a prefix – a string that the number starts with. The prefix is separated automatically and the remaining part of the number is transformed only.
- **Transformation regulativ**
enables to modify a number by removing a certain number of characters from the number beginning, or adding a new prefix.

Normalization

Line	Prefix	Remove count	Add number	Type	Description
19	+		000	Caller incoming	created by wizard
19			0	Caller incoming	created by wizard
0				Called outgoing	created by wizard

Fig. 3.55 - Normalisation

Use the Add icon to create a new LCR normalising rule. By clicking on it you get a rule defining form.




Fig. 3.56 - Normalisation – Add Rule

The meanings of the fields in the form are identical with the following columns of the normalising table:

- **Prefix**
the prefix that a number must start with to meet the transformation regulation. **This prefix is always removed automatically!**
- **Remove count**
a count of characters to be removed from the number beginning behind the prefix.
- **Add number**
the prefix to be added before the rest of the number after removal of the prefix and a defined count of digits.
- **Type**
defines at which stage the normalising rules shall be applied. There are four options: Incoming calling – on the calling number input, Incoming called – on the called number input, Outgoing calling – on the calling number output, Outgoing called – on the called number output.
- **Description**
any text that describes the meaning of a normalising rule.

Tariff Metering

Call tariff metering (AOC) in the 2N® OfficeRoute/2N® VoiceBlue Enterprise gateways is a sophisticated recording of the called time for each SIM card. Monitoring of free minutes is made with the aim to cut tariff costs and optimise the LCR process. The tariff-metering scheme divides a call into two time ranges. In each range tariff metering can be made according to different time units.

Add LCR tariff

Tariff name:

Line ID:

Time intervals:

Restore limit every day: ☐

Day of restore call limit:

Tariffication: the first units last seconds
 following units last seconds

Free minutes:

Free SMS:

Description:

Fig. 3 – Add LCR Tariff Form

Fig. 3.57 – Add LCR Tariff Form

- **Tariff rate name**
the user defined tariff rate name.
- **Line ID**
the SIM or line to which a tariff rate is applied.
- **Time intervals**
time when a tariff rate is applied.
- **Restore limit every day**
tick off to have the call limit (free minutes) restored every day.
- **Day to restore call limit**
specify a day in a month for the call limit (free minutes) to be restored.
- **Tariff metering**
settings for the counting of used seconds/minutes.
- **Free minutes, Free SMS**
count of minutes/SMS to be used during an accounting period (month or day).


Example in Fig. 3.57:

The tariff rate is applied to SIM card 89.....8413, only during weekdays and workdays (as defined in the *Time intervals* parameter). The limit is restored on the 1st day of each month (at a time as set in the unit). Accounting is made as follows: The first 60 seconds of the call are charged immediately, the next 30 seconds are not charged until the first 60 seconds elapse. The SIM card can be used for 300 outgoing minutes and 50 sent SMS messages per month. After the call limit is exceeded, no more outgoing calls may be made.

Blacklist

After output normalising and before switching the call to the found output line, the list of barred numbers (blacklist) is checked. If the number begins with a string included in the list the call is rejected. The list includes both whole telephone numbers and/or their initial parts (prefixes) only. Thus, e.g. all international calls or specially rated calls (erotic lines etc.) can be barred.

To adjust the barred numbers use the LCR menu in the group configuration tag. Select the blacklist item to display the list of barred numbers.



The screenshot shows a web interface for adding a blacklist item. On the left is a sidebar menu with categories: Devices, GSM, Mobility Extension, Fax, LCR (highlighted), and a sub-menu under LCR including Time intervals, Normalization, Tariffication, Blacklist (highlighted), Routes, and LCR test. The main content area is titled 'Add blacklist item' and contains two input fields: 'Regular expression:' and 'Description:'.

Fig. 4 – Blacklist

Fig. 3.58 – Blacklist

Regular expression

the initial part of the barred number (or a whole number).

Description

any text that describes the meaning of an item.

Routes

This window includes the list of existing routes and the route adding and removing options. A route means an outgoing trunk (bundle of SIMs, modules, SIP lines or DISA lines).

Fig. 3.59 – LCR Routes - Add Route Form


There is a route named 'Mobile Networks' in the figure above, which contains all GSM modules. It is used at all defined time intervals without CLI restriction (CLIR may be used for mobile networks only).


The form contains the following fields:

- **Route name**
the route name may contain any alphanumerical characters. Refer to the LCR rules in the preceding section.
- **Lines of route**
a list of available lines that form a group. To select/remove a line click on the respective item with the left-hand mouse button. You can select more list items at the same time by pushing the CTRL key along with the mouse click. The selected items are illuminated blue.
- **Time intervals**
define the routing rule time validity.
- **CLIP/CLIR**
enable/disable the caller's identification.
- **Description**
any text describing the meaning of an item.

LCR Test

The *LCR test* item in the Least Cost Router (LCR) menu in the *Telephony services* tag is used for testing changes in the LCR settings. Enter the caller's and called numbers

and click on the LCR test  icon below the form to initiate the LCR process simulation.



Input LCR test

Caller:

Called number:

Fig. 3.60 – LCR Test

After simulation, the normalised calling and called numbers plus the name of the successfully found output line or the reason why the line search was unsuccessful are displayed.


GSM Routing

Incoming calls from the GSM network are processed by simply being routed to a selected number in the VoIP network. The routing rule may be set for each SIM card of the GSM module separately.

While processing GSM incoming calls, the LCR first tries to find the Operator service according to the GSM module and then according to the SIM card number. After finding the service, it selects the line that is assigned to the Operator service for the incoming call. Finally, the calling number is normalised according to the normalising table.

Operator

To set routing click on the GSM routing reference. The Operator service must be set first. Click on the Operator item to display the table of available operators (see Fig. 3.61).



The interface shows a sidebar with a tree view containing 'Devices', 'GSM', 'Mobility Extension', 'Fax', 'LCR', and 'GSM routing'. Under 'GSM routing', there are sub-items: 'Normalization', 'GSM', 'SIM', and 'Operator' (which is selected). The main panel is titled 'GSM routing - Operator' and contains a toolbar with icons for adding, moving, deleting, and other actions. Below the toolbar is a table with the following data:

Service name	Operator number	VoIP line	Description
Operator 10 on line 16	<input type="checkbox"/> 10	SIP - Line to my SIP operator	created by wizard

Fig. 3.61 – GSM Routing – Operator

To add an Operator service click on the Add button. This displays the Operator service adding form (see Fig. 3.62).

Add GSM routing Operator service

Service name:

Operator number:

VoIP line: SIP - Line to my SIP operator ▼

Description:

Fig. 3.62 – GSM Routing – GSM Routing Operator Adding Form

- **Service name**
the field may contain any alphanumeric characters.
- **Operator number**
the VoIP network number to which the incoming GSM call is routed.
- **VoIP Line**
is the line used for dialling the VoIP network number (also a DISA line).
- **Description**
any text describing the meaning of the operator service.

To change the Operator service select the relevant line and click on the *Change* button. From now on follow the same steps as mentioned above with the exception that to save the changes click on the *Change* item.

To remove an Operator service, select the relevant line (as mentioned above) and click on *Remove*.

SIM

Click on the SIM item in the menu to the left to display the list of SIM routing rules (see Fig. 3.63).

Set SIM card routing

SIM card	Service name	Description
94203031021050	Operator 10 on line 16	

Fig. 3.63 – GSM Routing – SIM Card Routing

Click on the *Add routing of SIM card* item to display the routing rule adding form (see Fig. 3.64).

Add SIM card routing

SIM card:

Service name:

Description:

Fig. 3.64 – GSM Routing – SIM Card Routing Adding Form

- **SIM card**
select the SIM card number in this field. The incoming calls through the SIM number will be assigned to the service selected in the *Service name* field.
- **Service name**
the service through which the calls are to be routed into the VoIP network.
- **Description**
any text describing the SIM routing rule meaning.

GSM

Click on the *GSM* item in the menu to the left to display the list of GSM routing rules.







Devices	GSM routing - GSM				
GSM	GSM device	Service name	Description		
Mobility Extension	GSM module - 1	Operator 10 on line 16	created by wizard		
Fax	GSM module - 2	Operator 10 on line 16	created by wizard		
LCR	GSM module - 3	Operator 10 on line 16	created by wizard		
GSM routing					
• Normalization					
• GSM					

Fig. 3.65 – GSM Routing – GSM

Click on the *Add routing of GSM device* item to display the routing rule adding rule (Fig. 3.66).

Modify GSM device routing "/dev/ttyS3"

GSM device:

Service name:

Description:

Fig. 3.66 – GSM Routing – GSM Module Routing Rule

- **GSM device**
enter the GSM module number. The incoming calls through this module will be assigned to the service specified in the *Service name* field.
- **Service name**
the service through which the calls are to be routed into the VoIP network.

■ **Description**

any text describing the GSM routing rule meaning.

GSM Routing Normalising

The table normalises the calling (CLIP) numbers of the incoming calls from GSM network.

The normalisation should be made to display the calling number on the IP telephone in such manner, which enables proper routing of the back call into the 2N VoiceBlue Enterprise gateway.

If e.g. the gateway is configured to dial the calls into the GSM network by means of prefix 0 and the incoming CLIP from GSM network starts with +420, the prefix +420 must be detached and replaced by 0 (see Fig. 3.67).

Example:

Add GSM routing normalization

Prefix:

Remove count:

Add number:

Description:

Fig. 3.67 – GSM Routing - Normalising Adding Form

SIP Proxy

IP phones are registered to the internal SIP proxy. The SIP proxy serves as a registrar and location server and also as an RTP proxy for outgoing SIP proxy calls (e.g. calls to a SIP operator).

SIP proxy routing rules				
If prefix	Strip	Add	Do action	With parameter
sip:0	0		connect to LCR	SIP - 16
sip:6	0		connect to LCR	SIP - 16
sip:888	0		connect to LCR	SIP - 16
else	0		lookup registration	

Fig. 3.68 – SIP Proxy Main Screen

Fig. 3.68 shows an example of a completed routing table that gets displayed when you open the *SIP proxy* item. Each row represents one rule. Having received a call-establishing request, the SIP proxy searches this table from top to bottom for the appropriate routing rule.

Doing this, it compares the called destination with the value in the first table column. If the called subscriber's identifier starts with the prefix included in the *If prefix* field of the routing rule, the SIP proxy terminates searching and uses the rule found.

The last table row represents the so-called initial routing rule. It cannot be deleted. It is applied to all calls for which no explicit routing rule has been found. The routing rule defines what the SIP proxy should do with a call. It can reject it, forward it to another host and/or port, transfer it to a gateway VoIP line (i.e. to the LCR), or search for the called subscriber in the database of logged-in SIP telephones. Before one of the above mentioned operations is executed, it is possible to modify the called subscriber's identifier by removing a certain number of characters from the left or adding a new string to its beginning (refer to the Remove and Add columns).

The SIP proxy routing rules define routing (according the prefix of the dialled number). There are 2 rules by default - all dialled numbers with prefix 0 are routed to the internal SIP line and the remaining are to be looked up for registered IP phones.

Add rule

There is an *Add rule* icon below the table too. Click on it to display the rule defining form. Fig. 3.69 shows a form for setting the SIP proxy routing rules. The form fields correspond to the header of the table in Fig. 3.68.

Fig. 3.69 – Proxy Routing Rule Adding Form

The form and the table include the following fields:

- **If prefix**
if the called subscriber's URI (Uniform Resource Identifier) starts with this string, this rule is used for routing. In the SIP environment, the URI is introduced with the "sip:" prefix, which must be included in the value in this field.
- **Strip**
the number of characters following the "sip:" prefix to be removed from the URI before processing.
- **Add**
the string to be inserted in the URI behind the "sip:" prefix.
- **Do action**
defines what to do with a call. There are six potential actions in the pop-up menu but, in principle, there are only three of them – rejection, forwarding and connecting within the SIP proxy registrations. However, let us mention all the options briefly to have a full picture:
 - 1 Reject – the called line gets the busy tone;

- 2 Rewrite host – forwards the call to the same port of the selected host;
- 3 Rewrite port – forwards the call to the selected port of the same host (this can have the same effect as option 5);
- 4 Rewrite host and port – forwards the call to any port of the selected host;
- 5 Connect to LCR – connects the call to the selected gateway SIP line and thus to the LCR; and finally
- 6 Lookup registration – tries to search the SIP proxy registered users for the required URI and forward the call to the appropriate host.

■ **With parameter**

the above actions, except for the first and last ones, require a parameter to be set. This parameter is a new routing destination for call forwarding and the SIP line name for the Connection to 2N[®] OfficeRoute action.

In the figure - routing is done according to the prefix. The action might be 'Connect to LCR', 'Reject', 'Change host and port' and 'Lookup registration'. The parameter means here the routing destination of a call. There is a significant difference against the Normalising table – the prefix is not removed in the proxy rule.

Switch SIP Proxy Off

the proxy may be switched off when the unit is used as a UMTS router only.

If the integrated SIP proxy server is switched on, it may be switched off by clicking on the *Switch SIP Proxy off* menu item.

If the SIP proxy server is switched off, it may be switched on by clicking on *Switch SIP Proxy on* menu item.

Registrations

It is possible to monitor via the web interface which equipment units are registered at the SIP proxy.

3.7 Administration

Main Configuration

Here set the main parameters for using the device (e.g. PIN for SIM cards, DSP codecs – G.729 or G.723, Mobility Extension enable).

Fig. 3.70 – Main Configuration – Administration

- **Confirm remove**
a warning message before deleting settings.
- **SIM card routing**
enables the SIM card as a routing object.
- **Enable SIP session progress**
the SIP session process signalling.
- **Advanced config of regular expressions**
regular expressions provide a concise and flexible means for identifying strings of text of interest. This checkbox is for special cases.
- **DSP codec**
the type of codec used by the digital signal processor.
- **Default language**
the default language for administration.
- **Max user session time**
time in seconds for automatic logout from the administration after inactivity.
- **Simple login page**
check this option to enable a simple login page.

Set Time zone

Here set the time zone for 2N® OfficeRoute/2N® VoiceBlue Enterprise.




Fig. 3.71 – Main Configuration – Set Time zone

Synchronise Time

Synchronization of the 2N® OfficeRoute/2N® VoiceBlue Enterprise time with the PC time.




Fig. 3.72 – Main Configuration – Synchronise Time

Update Firmware

The firmware update helps you exchange the 2N® OfficeRoute/2N® VoiceBlue Enterprise firmware version. For updating, the firmware delivered by the gateway producer, or the firmware loaded from the producer's websites has to be used exclusively.

The firmware updating serves mainly for recording of repairs of potential failures or new software versions with updated functions.

To update the firmware, click on the *Update* item and then on the *Update firmware* item. This displays the firmware file adding dialogue.

Select the path to the firmware file by pushing the *Browse* button and upload the new firmware version into 2N® OfficeRoute/2N® VoiceBlue Enterprise by pushing the *Update* button.




Fig. 3.73 – Main Configuration – Update Firmware

Upload Licence

The licence file is necessary for switching on the purchased services provided by the 2N® OfficeRoute/2N® VoiceBlue Enterprise gateway.

Every newly purchased 2N® OfficeRoute/2N® VoiceBlue Enterprise unit is without the licence file. Before uploading, save the licence file on your PC hard-disk and remember the path to it.

To upload the licence file into the gateway click on the *Update* item in the *Setting* menu, and then on the *Upload licence* item. Then, the licence file adding dialogue will be displayed as shown in Fig. 3.74.




Fig. 3.74 – Main Configuration – Upload Licence

Configuration Backup

This menu helps you back up the whole configuration (including the licence and IP address). While uploading configuration you can check the 'Do not extract licence' item in order not to overwrite the gateway licence by the licence saved in the backup file.




Fig. 3.75 – Main Configuration – Configuration Backup

Reboot

Reboot the device. The rebooting process takes approximately 3 minutes.




Fig. 3.76 – Main Configuration - Reboot

3.8 States and Logs

States


This menu provides information on all 2N® OfficeRoute/2N® VoiceBlue Enterprise devices, registered VoIP extensions, calls and tariff metering states.

Tariff Metering

Count of free minutes/SMS messages.

Calls

Information on current calls.



From	Name	Line ID	To	Name	Line ID	Duration	State
10	unknown	SIP - Line to my SIP operator	751143775	0	0:01:12	0	

Fig. 3.77 – States - Calls

The columns include:

- **From**
the calling number.
- **Name**
the calling line name. It is completed only if this function is supported by the call-initiating IP telephone.
- **Line ID**
the line via which the call came to the gateway.
- **To**
the called number.
- **Name**
the called line name. It is completed only if this function is supported by the call-initiating IP telephone.
- **Line ID**
the line via which the call left the gateway.
- **Duration**
call duration time.
- **State**
connection status.

Devices

Signal strength and registration status with respect to external proxies.

States

- Tariffication
- Calls
- Devices
- Registrations

Call accounting

Logs

Devices

Line ID	Type	State	Info
19	SIP	DOWN	Line isn't registered
17	FXS	UP	Line UP
18	GSM	UP	Signal: -75 dBm, Technology: EDGE

Fig. 3.78 – States - Devices

Registrations

Information on registered users.

States

Tariffication

Calls

Devices

Registrations

Registrations

Registrations

sip:10@192.168.200.4

Fig. 3.79 – States - Registrations

Call Accounting

Provides detailed records on calls to mobile networks. The records on accomplished calls are saved into files in the text format. The file that the gateway currently saves call data into is called 'current.acc'. At the end of a predefined period of time, the file is renamed automatically and the gateway starts saving new call records into an empty file. The names of the closed files correspond with the respective period of time.

To display the list of saved call data files open the *Call accounting* menu in the States and Log tag.

States

Call accounting

Logs

Download logs

Connection speedometer

Call accounting

Report name

Size

Last changed

[current.acc](#)

0 b

2009/07/11 22:17:21

[0904.acc](#)

0 b

2009/05/01 01:59:59

[0905.acc](#)

0 b

2009/05/01 02:00:00

[0906.acc](#)

0 b

2009/06/12 01:50:50

Fig. 5 – Call Accounting

Fig. 3.80 – Call Accounting

Logs

Events that come into being during the gateway operation are recorded in operation journals for subsequent error analysis purposes. The events are divided into five groups and saved into separate files:

- **Debug**
extended information used for development/diagnostic purposes.
- **GSM AT**
a gateway - GSM module communication record. This journal includes all AT commands sent to the GSM modules by the gateway and responses sent back.
- **Data connection**
logging of communication between the module and the network between data connection.
- **Warning**
events that should not occur normally but their presence has no effect on the gateway behaviour.
- **Error**
errors that limit or jeopardise the gateway function. Their occurrence usually signals an approaching fatal error.

States

Call accounting

Logs

- Debug
- GSM AT
- Data connection
- Warning
- Error

Download logs

Connection speedometer

Modify logs settings

Clear debug log at startup: ☒

Add date to log: ☒

Logs per page:

Rotate size (kB):

Files count:

Rotate by:

Size: ☒

Day: ☐

Week: ☐

Month: ☐

Debug log level:

Other: ☒

SIP: ☒

H.323: ☒

2N PBX: ☐

GSM: ☒

Admin: ☒

LCR: ☒

DISA: ☐

FAX: ☐

FXS: ☐

POP3: ☐

SMTP: ☐

Fig. 3.81 – Logs - Settings

The form in Fig. 3.81 contains the following fields:

- **Clear debug log at start-up**
defines whether or not the tuning journal file should be deleted automatically upon the gateway power up.
- **Add date to log**
defines whether or not the gateway should add a timestamp to the events recorded.
- **Logs per page**
the number of lines to be displayed at the same time on one journal page.
- **Rotate size (kB)**
if the *Rotating* criterion is set in the *Size* (see below), the journal files shall be 'rotated off' whenever the defined size is exceeded (in kilobytes).
- **Files count**
the maximum number of 'rotated-off' files of each type that are stored in the gateway memory. The earlier ones are deleted automatically.
- **Rotate by**
the rotation criterion. The journal files are closed and renamed when a certain condition is satisfied and a new file is used for event recording. The files can be closed at the end of a defined period of time (day, week, or month) or when the specified size is achieved.
- **Debug log level**
defines which tuning record categories shall be recorded.

Download Logs

The viewing of the logs using a web browser as described in the preceding subsection is ineffective for complicated retrieval of events that happened in the distant past. In this case, it is more advantageous to download the journal files to your PC and view them using more sophisticated tools.

To download packed log files click on *Download*.




Fig. 3.82 – Download Logs

Connection Speedometer

In this section you can check your uploading and downloading speed. Also you can find here the signal strength for each module.




Fig. 3.83 – Connection Speedometer

3.9 Messaging

Thanks to an integrated SMS server, the 2N® OfficeRoute/2N® VoiceBlue Enterprise gateway is capable of not only sending but also receiving and delivering SMS.

Sending of SMS messages from the web interface. Every user with SMS rights can log in and send or receive SMS.




Fig. 3.84 – SMS – Inbox Messages

There are 4 folders:

- **Inbox**
a list of inbox SMS messages.
- **Sent**
a list of sent messages.
- **To send**
a list of stored messages that have not been sent yet.
- **Failed**
a list of messages that were not sent because of an error.

SMS sending

Click on the envelope icon in the right-hand bottom corner of 'Create a new message' to create a new SMS message.

Fig. 3.85 – SMS – New SMS

- **Recipient phone number**
the number on which the SMS will be sent.

- **Message**
the text of the SMS message.
- **Request status report**
tick off to get the delivery report.

SMS Delivery

2N® OfficeRoute/2N® VoiceBlue Enterprise's internal POP3 server provides SMS downloading from the gateway via e-mail.

SMS sending/receiving settings. The settings apply to both the web and SMTP/POP3 SMS sending/receiving ways.

SMS

SMS delivery

- VIP numbers
- SMTP IP access

Modify SMS delivery settings

Distribute incoming messages

Parse contents: ☒

Message response: ☒

VIP numbers: ☒

Save outgoing messages to Sent folder: ☐

Module 1 – Deliver SMS to user: Admin

Module 2 – Deliver SMS to user: Admin

Module 3 – Deliver SMS to user: Admin

Module 4 – Deliver SMS to user: Admin

For outgoing SMS use: GSM module 1

Automatic answers delivering

Answer arrives until: 10 Minutes

SMTP/POP3 server settings

Email domain name: 2n.cz

Delete SMS with POP3: Delete permanently

POP3 email subject: SMS from %n to %u, date %d

Maximum number of SMS per email: 1

SMTP IP access control: ☐

SMTP authentication required: ☒

Allow 16-Bit SMS: ☒

Allow SMS concatenating: ☒

Insert email sender to SMS: ☒

Insert email subject to SMS: ☒

Fig. 6 – SMS Delivery

The form contains the following fields:

- **Parse contents**
enables SMS delivery according to the contents.
- **Message response**
enables response deliveries.
- **VIP numbers**
enables deliveries according to the list of VIP numbers.

- **Save outgoing messages to Sent folder**
enables the saving of sent messages.
- **Module n**
Deliver SMS to user - choose the default user to receive incoming SMS for the GSM module.
- **For outgoing SMS use**
choose the GSM module for sending SMS.
- **Answer arrives until**
set the time for answer to sent SMS messages. Within this time the incoming SMS from the same telephone number as that in the sent SMS will be routed to the user who created the SMS. After this time the SMS will be routed to the user who is defined as the default user for GSM module n.
- **Email domain name**
the domain name must be equal to the POP3 domain name. The domain name is used for the SMS sender and SMS receiver for example - *SMS_sender_tel.number@domain name* and *SMS_receiver_tel.number@domain name*
- **Delete SMS with POP3**
an already read message could be deleted from the POP3 server. You can delete the message or mark it as already read (i.e. still available in the Inbox directory through the web-based interface, but the POP3 server can not see it).
- **POP3 email subject**
subject of the message to be filled in according to the 2N[®] OfficeRoute settings. You can use formatting strings in the text as well (%n – sender number, %u – receiver number, %d – date).
- **Maximum number of SMS per email**
the SMTP server makes one or more SMS messages from incoming e-mail (the maximum count of created SMS messages is set in the web-based interface. It is possible to set from 0 to 100 messages).
- **SMTP IP access control**
- **SMTP authentication required**
authentication goes through the username and password, which are used for registering to the web-based interface of 2N[®] OfficeRoute. Every SMS will be changed to e-mail in the Inbox directory after successful authentication.
- **Allow 16-bit SMS**
the server supports only 7-bit messages encoded according to ISO-8859-1 or 16 bit Unicode UTF-8 (messages with a different encoding could be illegible if received as SMS messages).
- **Allow SMS concatenating**
enables the merging of multiple SMS messages into one longer SMS message.
- **Insert email sender in SMS**
enables inserting the email sender in the SMS.
- **Insert email subject in SMS**
enables inserting the email subject in the SMS.

The server awaits e-mail in the Text/Plain, Text/HTML, Multipart/Mixed or Multipart/Alternative formats. From a Text/HTML message only the body of the HTML message, without formatting, is put in the SMS message. From Multipart/Mixed and

Multipart/Alternative messages only the first part of the message is used, enclosed between strings, mentioned in the header under the name 'boundary'.

The SMTP server makes one or more SMS messages from incoming e-mail (the maximum count of created SMS messages is set in the web-based interface. It is possible to set from 0 to 100 messages) in the form F:<sender><CRLF>S:<e-mail subject (max. 10 characters)><CRLF>e-mail body. Messages of the length of 160 characters are sent subsequently to the receiver via the Admin account (already sent SMS messages are available in the user Admin SENT directory).

VIP Numbers

There is a *VIP numbers* item in the *SMS delivery* menu in the *SMS* group tag. When you open it, you get a list of predefined VIP numbers that is searched whenever a new SMS is received if the *VIP number* delivery rule is active.



Fig. 3.86 – SMS Delivery – VIP Numbers


The columns include:

- **VIP number**
beginning (or the whole) of the SMS CLIP to which a list of addressees is assigned.
- **Description**
any text that describes the meaning of an item.
- **Available users**
a list of users to be delivered SMS.
- **Selected recipients**
a list of selected gateway users to be delivered the SMS messages that meet the specified criterion.

You can move user names from one list to another using the arrows located between the lists. To do that, select the user with the left-hand mouse button and then click on the arrow pointing at the other list.


SMTP IP Access

The SMTP server enables the sender IP address control as well as authentication. With the help of the web-based interface you can enable or disable the IP address control as well as set the list of allowed IP addresses.



The screenshot shows a web interface for configuring SMS delivery settings. On the left, there is a sidebar with 'SMS' selected, and sub-options for 'SMS delivery', 'VIP numbers', and 'SMTP IP access'. The main area is titled 'Add IP address' and contains two input fields: 'IP address/Mask:' and 'Description:'. Below these fields, a note states: 'Enter IP address/Mask in CIDR notation, e.g. 192.168.1.1/32 for single IP or 192.168.1.0/24 for whole network.'

Fig. 3.87 – SMS Delivery – SMTP IP Access



The screenshot shows a table titled 'Set IP address' with two columns: 'IP address/Mask' and 'Description'. The table contains two rows of data. Each row has edit and delete icons in the rightmost column.





IP address/Mask	Description		
192.168.20.0/24	My office		
80.60.23.152/32	My house		

Fig. 3.88 – SMS Delivery – List of IP Addresses Allowed for SMTP Access

4

Function and Use

This section describes the basic and extending functions of the product.
Here is what you can find in the section:

- Factory Reset

4.1 Factory Reset

If you need to do factory reset, follow the steps below:

1. Disconnect the gateway from the power supply.
2. Push and hold the Factory reset button.
3. Connect the gateway to the power supply.
4. Keep pushing the Factory reset button for at least 20 seconds.

After these steps the factory reset is executed.




Fig. 4.1 – Factory Reset Button

5

Technical Parameters

This section describes the technical parameters of the product.

5.1 Technical Parameters

VoIP

Signalling standards	SIP
Number of channels	4
Codecs	G.711 PCM (64 kbps) G.729A CS-ACELP (8 kbps) G.723.1 MP-MLQ/ACELP 6.3 kbps (optional)
PCM quantising	A-law / μ -law

Mobile networks

Mobile network type	UMTS WCDMA FDD EGSM 900 phase II GSM 1800 MHz
SIM cards	Plug-in 3V (small)
Transmission power	2W (1W)
Receiver sensitivity	-95 (-104) dBm

Antenna

Frequency	UMTS WCDMA FDD 850/1900/2100 MHz GSM 850/900/1800/1900 MHz
Impedance	50 Ω
Maximum output power	2W
Antenna connector type	SMA

Power Supply

Adapter	230V \pm 10%, 50/60Hz / 12V DC
Supply voltage	12V / 2.5A
Supply connector	DC jack, 2.1 mm

Power input	up to 20W
-------------	-----------

Interface

USB	Connector type A and B, host and master USB 2.0
Micro SD	
Ethernet	RJ-45 10/100 Base T
Protocols	IP, ICMP, TCP, UDP, DHCP, RTP, TELNET, SSH, HTTP, HTTPS, SMTP, SNMP, POP3

Operational Conditions

Temperature	0°C ÷ 40°C
Relative humidity	5 ÷ 90% non-condensing

Others

Dimensions (without connectors)	250×150×50 mm
CE certification	EN 60 950:2000, EN 55 024, EN 55 022 Class B

6

Supplementary Information

This section provides supplementary information on the product.

Here is what you can find in this section

- Regulations;
- Troubleshooting;
- List of Figures;
- General Instructions and Cautions.

6.1 Regulations

2N[®] OfficeRoute conforms to the following directives and regulations:

- Directive 1999/5/EC of the European Parliament and of the Council, of 9 March 1999 – on radio equipment and telecommunications terminal equipment and the mutual recognition of their conformity
- Directive 2006/95/EC of the European Parliament and of the Council of 12 December 2006 on the harmonisation of the laws of the Member States relating to electrical equipment designed for use within certain voltage limits
- Directive 2004/108/EC of the European Parliament and of the Council of 15 December 2004 on the approximation of the laws of the Member States relating to electromagnetic compatibility and repealing Directive 89/336/EEC
- Directive 2002/96/EC of the European Parliament and of the Council of 27 January 2003 on waste electrical and electronic equipment
- Regulation (EC) No 1907/2006 of the European Parliament and of the Council of 18 December 2006 concerning the Registration, Evaluation, Authorisation and Restriction of Chemicals (REACH), establishing a European Chemicals Agency, amending Directive 1999/45/EC and repealing Council Regulation (EEC) No 793/93 and Commission Regulation (EC) No 1488/94 as well as Council Directive 76/769/EEC and Commission Directives 91/155/EEC, 93/67/EEC, 93/105/EC and 2000/21/EC
- Directive 2002/95/EC of the European Parliament and of the Council of 27 January 2003 on the restriction of the use of certain hazardous substances in electrical and electronic equipment

6.2 Troubleshooting



For tips for the solution of other potential problems see faq.2n.cz.

6.3 List of Figures

Fig. 2.3– Gateway Holder - Wall Mounting	16
Fig. 2.4– Gateway Holder – Hanging	16
Fig. 2.5– Supply Adapter Connection	17
Fig. 2.6– PuTTY – Serial Console Access Configuration	18
Fig. 2.7– LAN Connection	19
Fig. 2.8– Antenna Connector Connection	20
Fig. 2.9– SIM Card Inserting Procedure	21
Fig. 2.10 – Serial Console Access – Main Menu	24
Fig. 2.11 – Serial Console – Network Configuration	26
Fig. 3.1 – Configuration Wizard - Introduction	30
Fig. 3.2 – Configuration Wizard – Administrator Password	31
Fig. 3.3 – Configuration Wizard – Time zone	31
Fig. 3.4 – Configuration Wizard – PIN Codes	32
Fig. 3.5 – Configuration Wizard – Data Connection	32
Fig. 3.6 – Configuration Wizard – Extension Number Allocation	33
Fig. 3.7 – Configuration Wizard – Passwords for Extensions	33
Fig. 3.8 – Configuration Wizard – SIP Provider	34
Fig. 3.9 – Configuration Wizard – Outgoing Calls through GSM/UMTS	35
Fig. 3.10 – Configuration Wizard – Incoming Calls	35
Fig. 3.11 – Configuration Wizard – Finish	36
Fig. 3.12 – Web Administration Login Page	37
Fig. 3.13 – Web Interface Desktop	38
Fig. 3.14 – Main Configuration	40
Fig. 3.15 – Filtering	40
Fig. 3.16 – Port Mapping	41
Fig. 3.17 – DHCP Server Setting Form	42

Fig. 3.18 – DNS Proxy Configuration	42
Fig. 3.19 – VRRP Configuration.....	43
Fig. 3.20 – Dynamic DNS Configuration	44
Fig. 3.21 – Data Connection – SIM Cards	44
Fig. 3.22 – Data Connection – Modify SIM Card Form	45
Fig. 3.23 – SNMP Configuration	46
Fig. 3.24 – List of Available Users	48
Fig. 3.25 – Add User Form.....	49
Fig. 3.26 – List of Available Groups	50
Fig. 3.27 – Group Adding Form	50
Fig. 3.28 – Ring Group Adding Form	51
Fig. 3.29 – VoIP PBX Arrangement	52
Fig. 3.30 – "Point-to-Point" Arrangement.....	53
Fig. 3.31 – VoIP-to-GSM Gateway with PBX.....	53
Fig. 3.32 – 2N® OfficeRoute as SIP Proxy.....	54
Fig. 3.33 – 2N® OfficeRoute as SIP - H.323 Gateway	54
Fig. 3.34 - Call Routing by VoIP PBX	55
Fig. 3.35 - Routing of Incoming Calls from VoIP	55
Fig. 3.36 - Routing of Incoming Calls from GSM	56
Fig. 3.37 – List of SIP Lines	57
Fig. 3.38 – Modify Internal SIP Line	58
Fig. 3.39 – H.323 Line Details.....	60
Fig. 3.40 – List of Available SIM Cards.....	62
Fig. 3.41 – Data Connection – Modify SIM Card Form	63
Fig. 3.42 – DISA Line	65
Fig. 3.43 – FAX Line	66
Fig. 3.44 – Fxs Line.....	67
Fig. 3.45 – Fxs Line - Modify.....	67
Fig. 3.46 – GSM - PINs	68

Fig. 3.47 – GSM – Audio Parametres	68
Fig. 3.48 – GSM – CLIPs	69
Fig. 3.49 – Services	70
Fig. 3.49 – Mobility Extension	70
Fig. 3.50 - T.38 Fax Relay Settings	71
Fig. 3.51 - List of LCR Rules	73
Fig. 3.52 - LCR – Add Rule	74
Fig. 3.53 - Time Intervals	75
Fig. 3.54 - Normalisation	75
Fig. 3.55 - Normalisation – Add Rule	76
Fig. 3.56 – Add LCR Tariff Form	77
Fig. 3.57 – Blacklist	78
Fig. 3.58 – LCR Routes - Add Route Form	79
Fig. 3.59 – LCR Test	80
Fig. 3.60 – GSM Routing – Operator	80
Fig. 3.61 – GSM Routing – GSM Routing Operator Adding Form	81
Fig. 3.62 – GSM Routing – SIM Card Routing	81
Fig. 3.63 – GSM Routing – SIM Card Routing Adding Form	82
Fig. 3.64 – GSM Routing – GSM	82
Fig. 3.65 – GSM Routing – GSM Module Routing Rule	82
Fig. 3.66 – GSM Routing - Normalising Adding Form	83
Fig. 3.67 – SIP Proxy Main Screen	83
Fig. 3.68 – Proxy Routing Rule Adding Form	84
Fig. 3.69 – Main Configuration – Administration	86
Fig. 3.70 – Main Configuration – Set Time zone	87
Fig. 3.71 – Main Configuration – Synchronise Time	87
Fig. 3.72 – Main Configuration – Update Firmware	87
Fig. 3.73 – Main Configuration – Upload Licence	88
Fig. 3.74 – Main Configuration – Configuration Backup	88

Fig. 3.75 – Main Configuration - Reboot	89
Fig. 3.76 – States - Calls	90
Fig. 3.77 – States - Devices	91
Fig. 3.78 – States - Registrations	91
Fig. 3.79 – Call Accounting	91
Fig. 3.80 – Logs - Settings	92
Fig. 3.81 – Download Logs	93
Fig. 3.82 – Connection Speedometer	94
Fig. 3.83 – SMS – Inbox Messages	95
Fig. 3.84 – SMS – New SMS	95
Fig. 3.86 – SMS Delivery – VIP Numbers	98
Fig. 3.87 – SMS Delivery – SMTP IP Access	99
Fig. 3.88 – SMS Delivery – List of IP Addresses Allowed for SMTP Access	99
Fig. 4.1 – Factory Reset Button	102

6.4 General Instructions and Cautions

Please read this User Manual carefully before using the product. Follow all instructions and recommendations included herein.

Any use of the product that is in contradiction with the instructions provided herein may result in malfunction, damage or destruction of the product.

The manufacturer shall not be liable and responsible for any damage incurred as a result of a use of the product other than that included herein, namely undue application and disobedience of the recommendations and warnings in contradiction herewith.

Any use or connection of the product other than those included herein shall be considered undue and the manufacturer shall not be liable for any consequences arisen as a result of such misconduct.

Moreover, the manufacturer shall not be liable for any damage or destruction of the product incurred as a result of misplacement, incompetent installation and/or undue operation and use of the product in contradiction herewith.

The manufacturer assumes no responsibility for any malfunction, damage or destruction of the product caused by incompetent replacement of parts or due to the use of reproduction parts or components.

The manufacturer shall not be liable and responsible for any loss or damage incurred as a result of a natural disaster or any other unfavourable natural condition.

The manufacturer shall not be held liable for any damage of the product arising during the shipping thereof.

The manufacturer shall not make any warrant with regard to data loss or damage.

The manufacturer shall not be liable and responsible for any direct or indirect damage incurred as a result of a use of the product in contradiction herewith or a failure of the product due to a use in contradiction herewith.

All applicable legal regulations concerning the product's installation and use as well as provisions of technical standards on electric installations have to be obeyed. The manufacturer shall not be liable and responsible for damage or destruction of the product or damage incurred by the consumer in case the product is used and handled contrary to the said regulations and provisions.

The consumer shall, at its own expense, obtain software protection of the product. The manufacturer shall not be held liable and responsible for any damage incurred as a result of the use of deficient or substandard security software.

The consumer shall, without delay, change the access password for the product after installation. The manufacturer shall not be held liable or responsible for any damage incurred by the consumer in connection with the use of the original password.

The manufacturer also assumes no responsibility for additional costs incurred by the consumer as a result of making calls using a line with an increased tariff.

Electric Waste and Used Battery Pack Handling



Do not place used electric devices and battery packs into municipal waste containers. An undue disposal thereof might impair the environment!

Deliver your expired electric appliances and battery packs removed therefrom to dedicated dumpsites or containers or give them back to the dealer or manufacturer for environmental-friendly disposal. The dealer or manufacturer shall take the product back free of charge and without requiring another purchase. Make sure that the devices to be disposed of are complete.

Do not throw battery packs into fire. Battery packs may not be taken into parts or short-circuited either.



2N TELEKOMUNIKACE a.s.

Modřanská 621, 143 01 Prague 4, Czech Republic
Tel.: +420 261 301 500, Fax: +420 261 301 599
E-mail: sales@2n.cz
Web: www.2n.cz