

# **AWK-6232-M12**

## **Hardware Installation Guide**

---

**Moxa AirWorks**

**Third Edition, April 2014**

**MOXA<sup>®</sup>**

© 2014 Moxa Inc. All rights reserved.  
Reproduction without permission is prohibited.

**P/N: 1802062320012**

## Notes for the Reader



### **WARNING**

Indicates that death or personal injury may occur if proper precautions are not taken.



### **ATTENTION**

Indicates that possible damage to this product or your property may result if proper precautions are not taken.

**NOTE** Highlights important information related to this product.

## Package Checklist

Moxa's AWK-6232-M12 is shipped with the following items. If any of these items is missing or damaged, please contact your customer service representative for assistance.

- AWK-6232-M12 wireless AP/bridge/client
- 4 Dual-band omnidirectional antennas (5/2 dBi, N-type male, 2.4/5 GHz)
- Wall mounting kit (includes 2 supports)
- Field-installable power plug
- Field-installable M12 8-pin male LAN plug
- 2 transparent plastic sticks for field-installable plugs
- 1 metal cap to cover M12-female LAN connector
- 1 metal cap to cover RJ45 connector
- 1 metal cap to cover M12-male DI/O connector
- Documentation and software CD
- Quick installation guide (printed)
- Warranty card

## Recommended SFP Accessories

### **SFP-1G series**

- SFP-1GSXLC:  
Small form factor pluggable transceiver with 1000BaseSX, LC, 0.5 km, 0 to 60°C
- SFP-1GSXLC-T:  
Small form factor pluggable transceiver with 1000BaseSX, LC, 0.5 km, -20 to 75°C
- SFP-1GLSXLC:  
Small form factor pluggable transceiver with 1000BaseLSX, LC, 2 km, 0 to 60°C
- SFP-1GLSXLC-T:  
Small form factor pluggable transceiver with 1000BaseLSX, LC, 2 km, -40 to 85°C

- SFP-1GLXLC:  
Small form factor pluggable transceiver with 1000BaseLX, LC, 10 km, 0 to 60°C
- SFP-1GLXLC-T:  
Small form factor pluggable transceiver with 1000BaseLX, LC, 10 km, -40 to 85°C
- SFP-1GLHLC:  
Small form factor pluggable transceiver with 1000BaseLH, LC, 30 km, 0 to 60°C
- SFP-1GLHLC-T:  
Small form factor pluggable transceiver with 1000BaseLH, LC, 30 km, -40 to 85°C
- SFP-1GLHXLC:  
Small form factor pluggable transceiver with 1000BaseLHX, LC, 40 km, 0 to 60°C
- SFP-1GLHXLC-T:  
Small form factor pluggable transceiver with 1000BaseLHX, LC, 40 km, -40 to 85°C
- SFP-1GZXLC:  
Small form factor pluggable transceiver with 1000BaseZX, LC, 80 km, 0 to 60°C
- SFP-1GZXLC-T:  
Small form factor pluggable transceiver with 1000BaseZX, LC, 80 km, -40 to 85°C
- SFP-1GEZXC:  
Small form factor pluggable transceiver with 1000BaseEZXC, LC, 110 km, 0 to 60°C
- SFP-1GEZXC-120:  
Small form factor pluggable transceiver with 1000BaseEZXC, LC, 120 km, 0 to 60°C

**NOTE** The above items come with the AWK-6232-M12 standard version. The package contents for customized versions may be different.

## Installation

Before installing the AWK-6232-M12, make sure that all items in the Package Checklist are in the box. In addition, you will need access to a notebook computer or PC equipped with an Ethernet port. The AWK-6232-M12 has a default IP address, user name and password that you must use when resetting or connecting to your AWK-6232-M12 device.

Default IP address: **192.168.127.253**

User name: **admin**

Password: **root**

Please read "**Chapter2 Getting Started**" in AWK-6232-M12 User's Manual for more details about installation and configuration.




## ATTENTION

For security reasons, we strongly recommend changing the password. To do so, go to **Maintenance** → **Password**, and then follow the on-screen instructions.

**NOTE** To make the change effective, you must save the change and then click **Restart** → **Save** and **Restart** button to apply all changes.


## Panel Layout of the AWK-6232-M12



## ATTENTION

Please **DO NOT** open or remove the vent (item **10**, in the diagram). The warranty will be invalid if the seal is removed. All exposed connectors, including items **1**, **2**, & **4-7**, should be tightly covered by suitable caps when they are not in use.


## Dimensions



Unit = mm (inch)

## Attaching Antennas

The AWK-6232-M12 includes two dual-band omnidirectional antenna by default. Attach the antennas as illustrated below.



**Step 1:** Use your fingers and hold the antenna metal N-type connector.

**Step 2:** Screw the antenna N-type connector (male) onto the AWK-6232-M12 device's N-type connector (female)



### Caution

Do not hold the rubber plate to screw the antenna on to the AWK-6232-M12 device.



### ATTENTION


Use the antennas correctly: Use 2.4GHz antennas if the AWK-6232-M12 operates in IEEE 802.11b/g/n. Use the 5GHz antennas for operations in IEEE802.11a/n. Make sure your antenna installation is within a safe area covered by a lightning protection or surge arrest system.

## Wall Mounting

In most applications, wall mount provides an easier installation. You will find it quite easy to mount AWK-6232-M12 on the wall, as illustrated below.


### STEP 1:

Attach the wall-mounting kit with M4 screws, as shown in the diagram below.



### STEP 2:

Mounting the AWK-6232-M12 on the wall requires 4 screws. Use the AWK-6232-M12 device, with wall-mounting kit attached, as a guide to mark the correct locations of the 4 screws. The heads of the screws are recommended to be between 5.5mm and 8.5 mm in diameter, and the shafts should not be more than 5.0 mm in diameter, as shown in the figure.



Do not screw the screws all the way in to the wall—leave a space of about 2 mm to allow room for sliding the wall-mounting kit between the wall and the screws.




### ATTENTION

You can test the screw head and shank size by inserting the screw into one of the keyhole shaped apertures of the wall mounting plates before it is screwed into the wall.

### STEP 3:


Once the screws are fixed into the wall, insert the four screw heads through the large opening of the keyhole-shaped apertures, and then slide the AWK-6232-M12 downwards, as indicated to the right. Tighten the four screws for added stability.



### ATTENTION

To avoid environmental vibration or shock, you can consider a robust installation with four bigger screws, which the shafts are between 7.0 mm and 8.5 mm in diameter, and fix the AWK-6232-M12 onto wall directly and tightly.

## DIN-Rail Mounting (Optional)




The DK-DC50131 die-cast metal kit can be bought separately, and enable easy and robust installation for the AWK-6232-M12. A pair of DK-DC50131s is needed for DIN-Rail mounting. To install the DIN-Rail mounting kits, tightly attach the two DIN-Rail mounting kits on the rear panel of AWK-6232-M12 with 12 screws. (6 screws for each kit)

### To Install

#### STEP 1:

Use the recessed button on the spring-loaded bracket to lock it into position.



#### STEP 2:


Insert the top of the DIN-Rail into the slot just below the upper hook of the DIN-Rail mounting kit. Push the AWK-6232-M12 toward the DIN-Rail until the DIN-Rail attachment bracket snaps into place.



### To Release


#### STEP 1:

Pull out the two spring-loaded brackets from the bottom until they are fixed in the "release" position.



#### STEP 2:

Pull the AWK-6232-M12 out and upward.



## Wiring Requirements



### WARNING

#### Safety First!

Be sure to disconnect the power cord before installing and/or wiring your Moxa AWK-6232-M12.

Calculate the maximum possible current in each power wire and common wire. Observe all electrical codes dictating the maximum current allowable for each wire size. If the current goes above the maximum ratings, the wiring could overheat, causing serious damage to your equipment.

You should also pay attention to the following items:

- Use separate paths to route wiring for power and devices. If power wiring and device wiring paths must cross, make sure the wires are perpendicular at the intersection point.  
**NOTE:** Do not run signal or communications wiring and power wiring in the same wire conduit. To avoid interference, wires with different signal characteristics should be routed separately.
- You can use the type of signal transmitted through a wire to determine which wires should be kept separate. The rule of thumb is that wiring with similar electrical characteristics can be bundled together.
- Keep input wiring and output wiring separate.
- It is strongly advised that you label wiring to all devices in the system when necessary.

## Grounding Moxa AWK-6232-M12

Grounding and wire routing help limit the effects of noise due to electromagnetic interference (EMI). Run the ground connection from the ground screw to the grounding surface prior to connecting devices.




### ATTENTION

This product is intended to be mounted to a well-grounded mounting surface, such as a metal panel. There must be no potential difference between two ground potentials, otherwise there is a risk that the device could be destroyed.

## Wiring the Redundant Power Inputs

The AWK-6232-M12 must be connected to a Power over Ethernet Plus (PoE+) IEEE 802.3at compliant power source or an IEC60950 compliant limited power source. When AWK-6232-M12 is powered via DC power, the M12 A-coding connector on the bottom panel is used for the AWK-6232-M12's two redundant inputs. The male, device-side pin assignment is shown below:



Pin	Power Input
1	V1+
2	V2+
3	V1-
4	V2-
5	GND



### ATTENTION

This product is intended to be supplied by a Listed Power Unit marked "Class 2" or "LPS" and rated O/P: 12 to 48 VDC, maximum 800mW.

Make sure External Power Adaptor (includes power cords and plug assemblies) provided with the unit is certified and suitable for use in your country.

Before connecting the AWK-6232-M12 to the DC power inputs, make sure the DC power source voltage is stable.



### ATTENTION

Do not use the PoE Injector. Instead, please use an IEEE802.3af or IEEE802.3at compliant PSE (Power Sourcing Equipment) for PoE+ (Power over Ethernet Plus) devices.

## Wiring the Digital Inputs and Relay Contact



### (Digital Output)

The AWK-6232-M12 has two sets of digital input—DI1 and DI2. Each DI comprises two contacts of the 8-pin M12 connector on the AWK-6232-M12's bottom panel. These two digital inputs can be connected to digital-output-enabled sensors for on-site status monitoring.

The AWK-6232-M12 also has one relay output, which consists of the two contacts. These relay contacts are used to detect user-configured events. The two wires attached to the Relay contacts form an open circuit when a user-configured event is triggered. If a user-configured event does not occur, the Relay circuit will be closed.

A field-installable plug, **M12A-8PF-IP67**, is recommended for connecting the AWK-6232-M12's DIs and relay.

Pin	Signal
1	Relay
2	
3	DI1 I1
4	DI1 COM_1
5	DI2 I2
6	DI2 COM_2
7	Reserved
8	



## Communication Connections


### Connecting the Data Lines

#### 10/100/1000BaseT(X) Ethernet Port Connection

AWK-6232-M12 has 10/100/1000BaseT(X) Ethernet ports (8-pin shielded M12 connector with A coding). The 10/100/1000BaseT(X) ports located on the AWK-6232-M12's bottom panel are used to connect to Ethernet-enabled devices. Below we show pinouts for both MDI (NIC-type) ports and MDI-X (HUB/Switch-type) ports.

#### Pinouts for the 10/100/1000BaseT(X) M12 (8-pin) Port

PIN	Con.
1	TRD3+
2	TRD4+
3	TRD4-
4	TRD1-
5	TRD2+
6	TRD1+
7	TRD3-
8	TRD2-






## ATTENTION


To ensure the IP68-rated connectivity, you must use a waterproof housing during any communication activities. An IP68-rated field installable plug, which is attached in AWK-6232-M12's accessory pack, may be needed in this case. The installation guide is shown below:

## Ethernet M12 Plug

### Dimensions (unit: mm)



### Installation




1. Refer to the pin assignment and solder wires with ①;
2. Then assemble ②, ③, ④, and ⑤ in order;
3. Test the plug to ensure the quality.

## RS-232 Connection

The AWK-6232-M12 has one RS-232 (8-pin RJ45) console port located on the bottom panel. Use either an RJ45-to-DB9 or RJ45-to-DB25 cable to connect the Moxa AWK-6232-M12's console port to your PC's COM port. You may then use a console terminal program to access the AWK-6232-M12 for console configuration.

### Console Pinouts for 10-pin or 8-pin RJ45

10-Pin	Description	8-Pin
1	-----	
2	DSR	1
3	RTS	2
4	GND	3
5	TxD	4
6	RxD	5
7	DCD	6
8	CTS	7
9	DTR	8
10	-----	



- NOTE**
1. The pin numbers for male DB9 and DB25 connectors, and hole numbers for female DB9 and DB25 connectors are labeled on the connector. However, the numbers are typically quite small, so you may need to use a magnifying glass to see the numbers clearly.
  2. The pin numbers for both 8-pin and 10-pin RJ45 connectors (and ports) are typically not labeled on the connector (or port). Refer to the Pinout diagram above to see how RJ45 pins are numbered.



## ATTENTION

For railway rolling stock applications, AWK-6232-M12 devices must use a galvanically isolated power supply that is compliant with the EN 50155 standard.

## LED Indicators

The front panel of the Moxa AWK-6232-M12 contains several LED indicators. The function of each LED is described in the table below.

LED	Color	State	Description
<b>PWR</b>	Green	On	Power is being supplied (from power input 1 or 2, or PoE)
		Off	Power is not being supplied
<b>FAULT</b>	Red	Blinking (slow)	Cannot get an IP address from the DHCP server (interval: 1 sec)
		Blinking (fast)	IP address conflict (interval: 0.5 sec)
		Off	Error condition does not exist
<b>STATE</b>	Green/ Red	Green	Software Ready
		Green, blinking	The AWK has been located by AWK Search Utility. (interval: 1sec)
		Red	Booting or Error condition
<b>WLAN 1 and WLAN 2</b>	Green/ Amber	Green, on	Device is connected to a WLAN in <b>Client/Slave</b> mode
		Green, blinking	Device is transmitting WLAN data in <b>Client/Slave</b> mode
		Amber, on	Device is connected to a WLAN in <b>AP/Master</b> mode
		Amber, blinking	Device is transmitting WLAN data in <b>AP/Master</b> mode
		Off	WLAN is not in use or not working properly

LED	Color	State	Description
LAN 1 and LAN 2	Amber/ Green	Amber, on	The 10/100Mbps link on the device's LAN port is active
		Amber, blinking	Device is transmitting LAN data at 10/100 Mbps
		Amber, off	10/100Mbps LAN port link is inactive
		Green, on	1000Mbps LAN port link is active
		Green, blinking	Device is transmitting LAN data at 1000 Mbps
		Green, off	1000Mbps LAN port link is inactive

## Specifications

WLAN Interface	
Standards:	IEEE 802.11a/b/g/n for Wireless LAN IEEE 802.11i for Wireless Security IEEE 802.3 for 10BaseT IEEE 802.3u for 100BaseTX IEEE 802.3ab for 1000BaseT IEEE 802.3at for Power over Ethernet Plus IEEE 802.1D for Spanning Tree Protocol IEEE 802.1w for Rapid STP IEEE 802.1Q VLAN
Spread Spectrum and Modulation (typical):	<ul style="list-style-type: none"> <li>• DSSS with DBPSK, DQPSK, CCK</li> <li>• OFDM with BPSK, QPSK, 16QAM, 64QAM</li> <li>• 802.11b: CCK @ 11/5.5 Mbps, DQPSK @ 2 Mbps, DBPSK @ 11 Mbps</li> <li>• 802.11a/g: 64QAM @ 54/48 Mbps, 16QAM @ 36/24 Mbps, QPSK @ 18/12 Mbps, BPSK @ 9/6 Mbps</li> <li>• 802.11n: 64QAM @ 300 Mbps to BPSK @ 6.5 Mbps (multiple rates supported)</li> </ul>
Operating Channels (central frequency):	US: 2.412 to 2.462 GHz (11 channels) 5.18 to 5.24 GHz (4 channels) EU: 2.412 to 2.472 GHz (13 channels) 5.18 to 5.24 GHz (4 channels) JP: 2.412 to 2.472 GHz (13 channels, OFDM) 2.412 to 2.484 GHz (14 channels, DSSS) 5.18 to 5.24 GHz (4 channels for W52)
Security:	<ul style="list-style-type: none"> <li>• SSID broadcast enable/disable</li> <li>• Firewall for MAC/IP/Protocol/Port-based filtering</li> <li>• 64-bit and 128-bit WEP encryption, WPA/WPA2-Personal and Enterprise (IEEE 802.1X/RADIUS, TKIP and AES)</li> </ul>
Transmission Rates:	802.11b: 1, 2, 5.5, 11 Mbps 802.11a/g: 6, 9, 12, 18, 24, 36, 48, 54 Mbps 802.11n: 6.5 to 300 Mbps (multiple rates supported)

TX Transmit Power:	802.11b: 1 to 11 Mbps: Typ. 18 dBm ( $\pm 1.5$ dBm) 802.11g: 6 to 24 Mbps: Typ. 18 dBm ( $\pm 1.5$ dBm) 36 to 48 Mbps: Typ. 17 dBm ( $\pm 1.5$ dBm) 54 Mbps: Typ. 15 dBm ( $\pm 1.5$ dBm) 802.11a: 6 to 24 Mbps: Typ. 17 dBm ( $\pm 1.5$ dBm) 36 to 48 Mbps: Typ. 16 dBm ( $\pm 1.5$ dBm) 54 Mbps: Typ. 14 dBm ( $\pm 1.5$ dBm)
TX Transmit Power MIMO:	802.11a/n (20/40 MHz): MCS15 20 MHz: Typ. 13 dBm ( $\pm 1.5$ dBm) MCS15 40 MHz: Typ. 12 dBm ( $\pm 1.5$ dBm) 802.11g/n (20 MHz): MCS15 20 MHz: Typ. 14 dBm ( $\pm 1.5$ dBm)
RX Sensitivity:	802.11b: -92 dBm @ 1 Mbps, -90 dBm @ 2 Mbps, -88 dBm @ 5.5 Mbps, -84 dBm @ 11 Mbps 802.11g: -87 dBm @ 6 Mbps, -86 dBm @ 9 Mbps, -85 dBm @ 12 Mbps, -82 dBm @ 18 Mbps, -80 dBm @ 24 Mbps, -76 dBm @ 36 Mbps, -72 dBm @ 48 Mbps, -70 dBm @ 54 Mbps 802.11a: -87 dBm @ 6 Mbps, -86 dBm @ 9 Mbps, -85 dBm @ 12 Mbps, -82 dBm @ 18 Mbps, -80 dBm @ 24 Mbps, -76 dBm @ 36 Mbps, -72 dBm @ 48 Mbps, -70 dBm @ 54 Mbps
RX Sensitivity MIMO:	802.11a/n: -68 dBm @ MCS15 40 MHz, -70 dBm @ MCS7 40 MHz, -69 dBm @ MCS15 20 MHz, -71 dBm @ MCS7 20 MHz 802.11g/n: -69 dBm @ MCS15 20 MHz, -71 dBm @ MCS7 20 MHz
<b>Protocol Support</b>	
General Protocols:	DNS, HTTP, HTTPS, IP, ICMP, SNMP, TCP, UDP, RADIUS, SNMP, PPPoE, DHCP, LLDP
AP-only Protocols:	ARP, BOOTP, DHCP, STP/RSTP (IEEE 802.1D/w)
<b>Interface</b>	
Default Antennas:	4 dual-band omnidirectional antennas, 5 dBi at 2.4 GHz, 2 dBi at 5 GHz, N-type (male)
Connector for External Antennas:	N-type (female)
LAN Ports:	2, 10/100/1000BaseT(X), auto negotiation speed (M12 female type)
Console Port:	RS-232 (waterproof RJ45-type)
LED Indicators:	PWR, FAULT, STATE, WLAN1, WLAN2, LAN1, LAN2
Alarm Contact (digital output, M12 male connector):	1 relay output with current carrying capacity of 1 A @ 24 VDC
Digital Inputs (M12 female connector): 2 electrically isolated inputs	<ul style="list-style-type: none"> <li>• +13 to +30 V for state "1"</li> <li>• +3 to -30 V for state "0"</li> <li>• Max. input current: 8 mA</li> </ul>

<b>Physical Characteristics</b>	
Housing:	Metal, IP68 protection
Weight:	1.8 kg
Dimensions:	224 x 147.7 x 64.5 mm (8.82 x 5.82 x 2.54 in)
Installation:	Wall mounting (standard), DIN-Rail mounting (optional), pole mounting (optional)
<b>Environmental Limits</b>	
Operating Temperature:	-40 to 75°C (-40 to 167°F)
Storage Temperature:	-40 to 85°C (-40 to 185°F)
Ambient Relative Humidity:	5% to 100% (non-condensing)
<b>Power Requirements</b>	
Input Voltage:	12 to 48 VDC, redundant dual DC power inputs or 48 VDC Power over Ethernet Plus (IEEE 802.3at compliant)
Connector:	M12 connector (male) with A-coding
Power Consumption:	Power Consumption: 12 to 48 VDC, 1.5 A (max.)
Reverse Polarity Protection:	Present
<b>Standards and Certifications</b>	
Safety:	UL 60950-1, EN 60950-1
EMC:	EN 301 489-1/17; FCC Part 15, Subpart B; EN 55022/55024
Radio:	EN 300 328, EN 301 893, DSPP (Japan)
Rail Traffic:	EN 50155, EN 50121-1/4
<b>Note: Please check Moxa's website for the most recent certification status.</b>	
<b>Reliability</b>	
MTBF (mean time between failures):	318,682 hrs
<b>Warranty</b>	
Warranty Period: 5 years Details: See <a href="http://www.moxa.com/warranty">www.moxa.com/warranty</a>	

## RESTRICTED ACCESS ONLY

This equipment is intended to be installed only in **restricted access locations** such as server rooms with limited access to SERVICE PERSONNEL or USERS who have not been instructed on how to handle the device. During normal operations, **this device can reach temperatures high enough to require special protection before handling**. Installation locations should be within locked, confined spaces that are accessible only with a key or through security identification systems.

**The external metal parts of this equipment will get extremely hot!!**

Before handling, service personnel must take special precautions to protect hands and body from serious injury.



## **ATTENTION**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.



## **ATTENTION**

Do not locate the antenna near overhead power lines or other electric light or power circuits, or where it can come into contact with such circuits. When installing the antenna. Take extreme care not to come into contact with such circuits, because they may cause serious injury or death. For proper installation and grounding of the antenna. please refer to national and local codes (for example, U.S.:NFPA 70, National Electrical Code, Artical810, Canada: Canadian Electrical Code, Section 54).

### **Technical Support Contact Information** **[www.moxa.com/support](http://www.moxa.com/support)**

#### Moxa Americas:

Toll-free: 1-888-669-2872

Tel: +1-714-528-6777

Fax: +1-714-528-6778

#### Moxa China (Shanghai office):

Toll-free: 800-820-5036

Tel: +86-21-5258-9955

Fax: +86-21-5258-5505

#### Moxa Europe:

Tel: +49-89-3 70 03 99-0

Fax: +49-89-3 70 03 99-99

#### Moxa Asia-Pacific:

Tel: +886-2-8919-1230

Fax: +886-2-8919-1231